



Temperature Control Equipment Precautions 1

Be sure to read this before handling. Refer to front matters 42 and 43 for Safety Instructions and the main text for Specific Product Precautions on every series.

Selection

⚠ Warning

1. Confirm the specifications.

Fully understand the applications, environment, fluids and other operating conditions. Use this product within the specified range shown in this catalog. Using outside the specified range can cause injury, damage, or malfunction. When in doubt, please contact SMC beforehand.

2. Secure the performance margin.

When you consider the product's cooling/heating performance or flow characteristics, allowance must be made because there are heat loss from the piping, etc. or pressure drop.

Operating Environment / Storage Environment

⚠ Warning

1. Observe the ambient temperature range.

The operating ambient temperature range must be within the specification range shown in this catalog.

Use caution because using beyond the range will lead to damage, breakage or malfunction.

2. Avoid using and storing in the following environment because it will lead to malfunction.

- 1) In locations where water, water steam, salt water, and oil may splash on the product.
- 2) In locations where a large amount of particles are airborne.
- 3) In locations with an atmosphere of corrosive or explosive gases, solvents, or chemicals.
(This product is not explosion proof.)
- 4) In locations which receive direct sunlight or radiated heat.
(Protect from direct sunshine to avoid the resin from deteriorating by ultraviolet rays or increasing the temperature.)
- 5) In locations where temperature substantially changes.
- 6) In locations where there is a heat source nearby and the ventilation is poor.
(Insulate the heat source or ventilate well to avoid damages caused by the heat or temperature increase, such as softening.)
- 7) In locations where condensation occurs.
- 8) In locations where strong magnetic noise occurs.
(In locations where strong electric fields, strong magnetic fields and surge voltage occur.)
- 9) In locations where static electricity occurs, or conditions which make the product discharge static electricity.
- 10) In locations where high frequency occurs.
- 11) In locations where damage is likely to occur due to lightning.
- 12) In locations where impacts or vibrations occur.
- 13) In conditions where a massive force strong enough to deform the product is applied or a weight from a heavy object is applied.
- 14) In locations more than 1000 m in altitude (except storage, transportation).

Fluid

⚠ Warning

1. Type of fluids

- 1) The operating fluids must be used within the specified range shown in this catalog.
Please consult with SMC when using the product with other fluids.
- 2) When foreign objects may be mixed with a fluid, install a filter.

Transportation / Transfer / Movement

⚠ Warning

1. Product transfer should be performed by a knowledgeable and experienced person.

Especially, transferring a heavy object is dangerous.

Use adequate caution to prevent falling down or dropping accidents from occurring.

2. Avoid transportation in the following environment because it will lead to breakage.

- 1) In conditions where strong shock and vibrations occur.
- 2) In operating and storage environments other than those specified.

3. Caution when transferring a heavy object

This product is heavy. Use adequate caution to avoid injury when picking up and setting down the product, and falling and dropping accidents should be avoided.

4. Before moving this product, remove operating fluid, facility water from the inside of this product.

Mounting / Installation

⚠ Warning

1. Installation should be performed by a knowledgeable and experienced person.

Especially, installation of a heavy object is dangerous.

Use adequate caution to avoid falling and dropping accidents from occurring.

⚠ Caution

1. Provide space for ventilation and maintenance.

Provide enough space for the ventilation requirement of each equipment. Otherwise, a cooling malfunction or operation stoppage may occur. Also, provide space required for maintenance.

2. Verify the mounting orientation.

Mount and install horizontally.



Temperature Control Equipment Precautions 2

Be sure to read this before handling. Refer to front matters 42 and 43 for Safety Instructions and the main text for Specific Product Precautions on every series.

Piping

Warning

- 1. For this product and future equipment, design of the piping system should be performed by a knowledgeable and experienced person.**
- 2. Work performed on the piping should be done by a knowledgeable and experienced person.**
If work performed on the piping is done by a less knowledgeable and inexperienced person, it will likely lead to operating fluid leakage, etc.
- 3. Thoroughly read the operating manual.**
Read the operating manual completely before piping. Also, keep the manual where it can be referred to as necessary.
- 4. Tighten threads with the proper tightening torque.**
When installing piping, etc., follow the given torque levels below.

Piping Tightening Torque

Connection thread	Proper tightening torque (N·m)
M5	1.5 to 2
Rc 1/8	7 to 9
Rc 1/4	12 to 14
Rc 3/8	22 to 24
Rc 1/2	28 to 30
Rc 3/4	28 to 30
Rc 1	36 to 38
Rc 1 1/4	40 to 42
Rc 1 1/2	48 to 50
Rc 2	48 to 50

- 5. Confirm the leakage of fluid.**
Confirm that the hose or tubing is not pulled out and that there is no leakage in the fitted parts.

Caution

- 1. Refer to the Fittings and Tubing Precautions (Best Pneumatics No. 6) for handling one-touch fittings.**
- 2. Preparation before piping**
Before piping is connected, it should be thoroughly blown out with air (flushing) or washed to remove chips, cutting oil and other debris from inside the pipe.
- 3. Use caution regarding the flowing direction of the fluid.**
When installing piping to a product, do not mistake the flow direction of supply port, etc. Check "IN" and "OUT" or labels and the operating manual before connection.
- 4. Sealant tape**
When installing piping or fitting into a port, ensure that sealant material does not enter the port internally. When using sealant tape, leave 1.5 to 2 threads exposed on the end of pipe/fitting.
- 5. Take countermeasures against condensation.**
Depending on the operating condition, condensation may occur in the piping. In such a case, take countermeasures such as installing insulation material, etc.

HRG

HRGC

HRZ

HRW

HEC

HEB

HED

HEA



Temperature Control Equipment Precautions 3

Be sure to read this before handling. Refer to front matters 42 and 43 for Safety Instructions and the main text for Specific Product Precautions on every series.

Electrical Wiring

Warning

1. Electrical wiring job should be performed by a knowledgeable and experienced person.

Power supply facilities and wiring works should be implemented in accordance with the electric facilities technical standards and provisions and conducted correctly.

2. Mounting a dedicated ground fault circuit interrupter

As a countermeasure against current leakage, install a ground fault circuit interrupter (GFCI) in the main power supply.

3. Check the power supply.

If this product is used with voltages other than specified, it will likely lead to a fire or an electrical shock. Before wiring, confirm the voltage, volume, and frequency.

Confirm that the voltage fluctuation is within $\pm 10\%$ of the specified value.

4. Grounding

Be certain to ground (frame ground) with class D grounding (grounding resistance of 100 Ω or less).

Can be grounded with the PE line of the power supply cable.

Also, do not use together with equipment that generates a strong electrical magnetic noise or high frequency noise.

5. Wiring cable should be handled with care.

Do not bend, twist or stretch the cord or cable.

6. Wire with an applicable size cable and terminal.

In the event of attaching a power supply cable, use a cable and terminal size which is suitable for the electrical current of each product.

Forcibly mounting with an unsuitable size cable will likely result in a fire.

7. Avoid wiring the signal line and power line in parallel.

Since there may be a possibility of malfunction from noise, avoid parallel wiring between the temperature sensor line, communication line, signal line of alarm line, etc. and the power line and high voltage line. Also, do not place them in the same wiring tube.

Facility Water Supply

(Water-cooled refrigeration)

Warning

1. Be certain to supply the facility water.

- 1) Prohibition of water-cut operation, very little flow rate of water operation.

Do not operate under the condition that there is no facility water or where there is very little flow rate of water is flowing.

In this kind of operation, facility water temperature may become extremely higher. It is dangerous enough the material of hose may soften and burst when the piping supplying the facility water is connected with hose.

- 2) Actions to be taken when an emergency stop occurs due to high temperature.

In case a stop occurs due to extremely high temperature resulting from a decrease in the facility water flow rate, do not immediately flow facility water. It is dangerous enough the material of hose may soften and burst when the piping supplying the facility water is connected with hose.

First, naturally let it cool down by removing the cause of the flow rate reduction. Secondly, confirm that there is no leakage again.

Caution

1. Facility water quality

- 1) Use the facility water within the specified range as shown below.

When using with other fluid than facility water, please consult with SMC.

- 2) When it is likely that foreign objects may enter the fluid, install a filter (20 mesh or equivalent).

Facility Water Quality Standard

The Japan Refrigeration and Air Conditioning Industry Association
JRA GL-02-1994 "Cooling water system – Circulation type – Circulating water"

	Item	Unit	Standard value
Standard item	pH (at 25°C)	—	6.5 to 8.2
	Electrical conductivity (25°C)	[μ S/cm]	100* to 800*
	Chloride ion (Cl ⁻)	[mg/L]	200 or less
	Sulfuric acid ion (SO ₄ ²⁻)	[mg/L]	200 or less
	Acid consumption amount (at pH4.8)	[mg/L]	100 or less
	Total hardness	[mg/L]	200 or less
	Calcium hardness (CaCO ₃)	[mg/L]	150 or less
Reference item	Ionic state silica (SiO ₂)	[mg/L]	50 or less
	Iron (Fe)	[mg/L]	1.0 or less
	Copper (Cu)	[mg/L]	0.3 or less
	Sulfide ion (S ₂ ⁻)	[mg/L]	Should not be detected.
	Ammonium ion (NH ₄ ⁺)	[mg/L]	1.0 or less
	Residual chlorine (Cl)	[mg/L]	0.3 or less
	Free carbon (CO ₂)	[mg/L]	4.0 or less

* In the case of [M Ω -cm], it will be 0.00125 to 0.01.



Temperature Control Equipment Precautions 4

Be sure to read this before handling. Refer to front matters 42 and 43 for Safety Instructions and the main text for Specific Product Precautions on every series.

Operation

Warning

1. Handle and operate after the safety of this product and the whole system are confirmed.

For this product and incidental equipment, operate this product by a knowledgeable and experienced person.

2. Before operation, confirm the safety of mounting, installation, piping and electrical wiring conditions.

1) Confirm that the mounting and installation conditions are safe.

2) Confirm that the circulating fluid is filled and that the fluid level is within the display range.

3) Confirm whether the valve is open or closed and that the hose and resin tube are not twisted.

It is dangerous when the valve in the piping is closed because the circulating fluid and the facility water will not flow and the fluid pressure will increase.

4) Confirm the flow direction of the fluid.

Be certain that the flow direction of the fluid (inlet/outlet direction) is connected correctly.

5) Confirm that the electrical wiring condition is safe.

Incorrect wiring will lead to malfunction or breakage of the product. Confirm that there is no error in wiring before operation.

6) When using the product with a 3-phase power supply, confirm the connection.

If the phase order is incorrect, the pump, etc. will run in reverse, or the phase-reversal relay will activate and the product will not operate.

In this case, after cutting off the main power supply, reverse 2 wires out of the 3 wires and connect them in the correct phase order.

3. Do not remove the external panel during energization or operation.

If removed, there are the dangers of electrical shock, burn, frostbite, injury from a rotating object.

4. Avoid operating with a lower flow.

Avoid operating with a lower flow because the temperature control may become unstable or the service life of the pump may shorten.

5. Confirm the safety during the operation.

During the operation, if an emergency is detected, stop this product immediately and cut off the power supply breaker.

6. When not used for long periods of time, confirm the safety once again prior to beginning its operation.

Maintenance

Warning

1. Perform maintenance inspection according to the procedures indicated in the operating manual.

If handled improperly, malfunction and damage of machinery or equipment may occur.

2. Maintenance operations

Improper handling of compressed air is dangerous. Therefore, in addition to observing the product specifications, replacement of elements and other maintenance activities should be performed by personnel having sufficient knowledge and experience pertaining to pneumatic equipment.

3. Pre-maintenance inspection

When removing this product, cut off the electric power, and be certain to shut off the supply pressure and exhaust the compressed air in the system. Proceed only after confirming that all pressure has been released to the atmosphere.

4. Post maintenance inspection

After installation or repair, reconnect compressed air and electricity and conduct appropriate inspections to confirm proper operation. If there is an audible air leakage, or if the equipment does not operate properly, stop operation and confirm that the equipment is installed correctly.

5. Modification prohibited

Do not modify or reconstruct the unit.

6. Stopping for long periods of time

When not using for long periods of time, remove the fluid (circulating fluid, facility water) and cut off the main power supply.

7. Removal of product

Take the stop/inspection measures and confirm that there is no danger before the product is removed.

In the event of removing the product, discharge the used fluid and clean the inside of the piping.

When a dangerous fluid or polluted fluid is left, it is likely that the polluted area will be enlarged or an accident will occur.

8. Disposal of product

When the product is disposed, it must be in compliance the ordinance or rules of the local municipality.

Ask for help from a professional industrial waste disposal company.

In particularly, in the case of a refrigerated type product, entrust a company to collect the refrigerant, etc.

In that case, the customer may be requested to submit a certificate that is showing the type of operating fluid and whether any quantity is left. These procedures are the responsibility of the customer.

9. Preparation of a backup product

In order to keep the downtime of a customer's system to a minimum, prepare a backup product, when necessary.

HRG

HRGC

HRZ

HRW

HEC

HEB

HED

HEA