


# CG1R-Z Series

ø20, ø25  
ø32, ø40  
ø50, ø63




## Construction

### With rubber bumper



### With air cushion



\* The numbers correspond with those in the "Construction" of the CG1R-Z series in the **Web Catalog**.

### Seal Kit List

No.	Description	Material	Note
16	Rod seal	NBR	19 is a non-replaceable part, so it is not included in the seal kit.
17	Piston seal		
18	Tube gasket		
19	Valve seal		

### Replacement Parts: Seal Kit

Bore size (mm)	Part no.	Contents
20	CG1N20Z-PS	Set of nos. 16, 17, 18
25	CG1N25Z-PS	
32	CG1N32Z-PS	
40	CG1N40Z-PS	

\* The seal kit includes a grease pack (10 g).  
Order with the following part number when only the grease pack is required.

**Grease pack part no.: GR-S-010 (10 g)**

### Disassembly/Replacement

## ⚠ Caution

#### 1. Do not replace the bushings.

The bushings are press-fit. To replace them, they must be replaced together with the cover assembly.

#### 2. To replace a seal, apply grease to the new seal before installing it.

If the cylinder is put into operation without applying grease to the seal, it could cause the seal to wear significantly, leading to premature air leakage.

#### 3. Cylinders with ø50 or larger bore sizes cannot be disassembled.

When disassembling cylinders with bore sizes ø20 through ø40, grip the double flat part of either the head cover or the rod cover with a vise and loosen the other side with a wrench or a monkey wrench, etc., and then remove the cover. When re-tightening, tighten approximately 2 degrees more than the original position.

(Cylinders with ø50 or larger bore sizes are tightened with a large tightening torque and cannot be disassembled. If disassembly is required, please contact SMC.)