


4 Name of Parts and Accessories (continued)


4.4 Name of Parts and Outline Dimensions

HRSF150/200-A*-40-*



Note: View 'A-A' see section 6.5.1 Anchor bolts

HRSF150/200-W*-40-*



Note: View 'A-A' see section 6.5.1 Anchor bolts


5 Transportation, Transfer and Moving

Caution

- Never lay the product on its side. The compressor oil will leak into the refrigerant piping, which may cause early failure of the compressor.
- Drain the residual fluid from the piping as much as possible to prevent any spillage.
- Moving the product by casters (only applicable to option "-A", refer to 3 How to Order) should be done by 2 persons or more.
- Raise the adjuster feet and push the corners of the product when moving the product using the casters.
- Do not hold the product by the piping connections or panel handles when moving by casters.

Warning

- The product is a heavy object (Refer to 2.1 Product specifications for weights).
- Moving by forklift and slinging should be done by trained personnel who have the required licenses.
- Be sure to use all four eye bolts when slinging the product.
- The slant angle of each rope should be 60 degrees or less.
- make sure that the fork does not damage the cover panel or piping port.



6 Installation

Warning

- Do not set up the product in places possibly exposed to leakage of flammable gas. Should any flammable gas stay around the product, the product may cause a fire.
- This product use flammable refrigerant. Do not install in public hallways or lobbies. Install it in a place with a floor space area of 10m² or more.
- Keep clear of obstruction all ventilation openings in the appliance enclosure or in the structure for building-in
- The product is not dust-proof. If used in an environment with dust, it may accumulate inside the product and cause not only a malfunction but also a fire hazard.

Caution

- Keep the product upright on a rigid and flat floor which can resist the weight of the product. Take precautions to prevent the product from tipping over. Improper installation may cause water leakage, tipping, damage of the product or injure the operator.
- Keep the ambient temperature of the product between -5 to 45°C. Operation out of this ambient temperature range may cause a malfunction of the product and the safety device may activate. This will result in the product stopping operation.
- The installer/end user is responsible for carrying out an acoustic noise risk assessment on the equipment after installation and taking appropriate measures as required.
- The product is not designed for clean room. The pump and ventilating fan inside the product generate particles.

6 Installation (continued)

6.1 Types of Hazard Labels

The product has various potential hazards which are marked with warning labels.

Warning related to Electricity

	This symbol stands for a possible risk of electric shock.
--	---

Warning related to High Temperatures

	This symbol stands for a possible risk of hot surface and burns.
--	--

Warning related to Rotating Objects

	This symbol stands for a possible risk of cutting fingers or hand, or entanglement by rotating fan (For air-cooled type).
--	---

Warning related to other General Dangers

	This symbol stands for general danger.
--	--

Warning related to Fire Hazards

	Any of these symbols represent a Fire Hazard.
	This product use a flammable refrigerant (R454C).

6.2 Environment

The product must not be operated, installed, stored or transported in the following conditions. Potential malfunction or damage to the product may occur if these instructions are disregarded.

- Do not use in an environment where corrosive gases, chemicals, salt water or steam are present.
- Do not use the product in an area of high temperature and humidity which cannot be exhausted, or where it is exposed to corrosive substances. Cooling failure can result.
- Do not use in environment exposed to dust or powder material.
- Do not use the product outdoors. If the product is exposed to rain or water splash it may cause electrical shock, fire or failure.
- Do not use in an explosive atmosphere.
- Do not install in a location exposed to direct sunlight and radiant heat.
- Do not install in a location subjected to vibration or impact.
- Do not install subjected to strong electromagnetic noise (intense electric field, intense magnetic field, or surges).

- Do not install subjected to static electricity, or conditions where static electricity can discharge to the product.
- Do not install subjected to strong high frequencies radiation.
- Do not use in locations at altitudes of 3000m or higher (except for product storage and transport), refer to the Operation Manual section '3.2.1 Environment'.
- Do not install in a location without adequate space for maintenance.

6.2.1 Installation at altitudes of 1000m or more

Due to the lower air density, the heat radiation efficiencies of the devices in the product will be lower in the location at altitude of 100m or higher. So, the maximum ambient temperature for the thermo-chiller operation and the cooling capacity will be reduced. See table below for details.

Altitude	Max. ambient temp. (°C)	Cooling capacity correction coefficient	Cooling capacity (kW)	
			HRSF150-A*-40-*	HRSF200-A*-40-*
Less than 1000m	45	1.00	15.70	20.50
1000m - less than 1500m	42	0.85	13.34	17.42
1500m - less than 2000m	38	0.80	12.50	16.40
2000m - less than 2500m	35	0.75	11.77	15.37
2500m - less than 3000m	32	0.70	10.99	14.35

6.3 Location

Caution

If the air-cooled product radiates heat from the air vent of the cooling fan. If the product is operated with insufficient air ventilation the internal temperature can exceed 45°C, which can affect the performance and life of the product. To prevent this, ensure that suitable ventilation is available (see below).

6.3.1 Installation of multiple products

Keep sufficient space between products so that the air vented from one product will not be taken in by other products.

6.3.2 Installation at indoor site

- In case of facility having a large installation area (that can vent air naturally) – Make an air outlet on a wall at a high level and an air inlet at a low level, to allow for adequate air flow.
- In case of facility having a small installation area (that cannot vent air naturally) – Make a forced air exhaust vent on a wall at a high level and an air inlet on a wall at a low level.

6 Installation (continued)

6.2 Installation (continued)

- Using ducts to exhaust the air – In case the indoor site cannot accept the exhaust air from the product or/and is air conditioned, ventilate by installing a duct on the outlet ventilation of the product. Do not fasten the duct on the outlet ventilation of the product directly. Leave a space which is equal or greater than the duct's diameter. Use a fan for the duct that considered the ventilation resistance of the duct.

6.3.3 Radiation and Ventilation for Air-cooled Products

Model	Heat radiation (kW)	Required ventilation amount m ³ /min	
		Differential temp. of 3°C between inside and outside if installation area	Differential temp. of 6°C between inside and outside if installation area
HRSF150-A*-40-*	Approx. 29	490	245
HRSF200-A*-40-*	Approx. 35	590	295


6.3.4 Radiation and Facility Water for Water-cooled Products

Model	Heat radiation (kW)	Facility water specifications
HRSF150-W*-40-*	Approx. 27	Refer to Operation Manual section "8.1. Specifications".
HRSF200-W*-40-*	Approx. 34	

6.4 Installation and Maintenance Space

Caution

Have enough space for the ventilation for the product. Otherwise, it may cause a lack of cooling capacity or/and stoppage of the product. Have enough space for maintenance.




6.5 Installation Procedure

Caution

Install the product on a horizontal and level floor.


6.5.1 Anchor Bolts

Prepare M10 anchor bolts that are appropriate to the material of the floor that the product will be installed. Drive the anchor bolts at least two places of the left and right side of the product (four places in total). Refer to the dimensions below.



6.5.2 How to mount the product

- Insert the product to the anchor bolts that were previously driven on the level floor.
- Fasten the nuts to the anchor bolts.
- Make sure that there is no looseness on all the anchor bolts and nuts.




6 Installation (continued)

6.5.3 For Option A or Caster Adjuster-foot kit (HRS-KS002/KS003)

Caution

In case of using Caster Adjuster-foot kit, be sure to use the adjuster foot to install on the floor. The adjuster foot is not earthquake-proof. Make an earthquake resistant measure by the customer side.

Note: Refer to the Operation Manual for the separately sold accessory for further details of the swivel caster and the adjuster foot set.



6.6 Electrical Wiring

Warning

- Do not modify the internal electrical wiring of the product. Incorrect wiring may cause electrical shock or fire. Also modifying the internal wiring will void the product's warranty.
- NEVER connect the ground to a water line, a gas pipe or a lightning conductor.

Warning

- The installation of electrical equipment and wiring work should only be performed by personnel with sufficient knowledge and experience.
- Be sure to shut off the user's power supply. Wiring with the product energized is strictly prohibited.
- The wiring must be conducted using cables complying with information in section "6.6.1 Power Supply Specifications, Power Supply Cable and Earth Leakage Breaker". The wiring must be firmly secured into the product to prevent the external force of cables being applied to the terminals. Incomplete wiring or improper securing of wiring may cause electric shocks, excessive heat and fire.
- Ensure a stable power supply with no voltage surges.
- Ensure than an Earth Leakage Breaker is used in the power supply of the product. See section "6.6.1 Power Supply Specifications, Power Supply Cable and Earth Leakage Breaker" for details.
- Use a power supply suitable for the specification of the product. Be sure to connect the ground connection.

6.6.1 Power Supply Specifications, Power Supply Cable and Earth Leakage Breaker

Prepare the power supply shown in the following table. For the connection between the product and power supply, use the power supply cable and earth leakage breaker shown below. An earth leakage breaker must be mounted to a position where the breaker is easily accessible and close to the thermo-chiller.

Model	Power supply voltage	Terminal block screw diameter	Recommended crimp terminal x size²	Cable qty. x size²	Earth leakage breaker¹	
Rated						

6 Installation (continued)

⚠ Warning

Be sure to lock out and tag out the breaker of the facility power supply (customer power supply facility) before wiring.

⚠ Warning


Be sure to connect the power supply cable from the product side first, and then connect the breaker of the facility power supply (the user's machine power supply).

⚠ Caution


When the panel is removed or mounted, be sure to wear protective shoes and gloves to prevent injury with the edge of the panel.

6.7.1 Power Supply Cable Wiring


1. Remove four screws to remove the front panel for the electrical unit.



2. Hold the handle and put up the front panel of the electrical unit, and remove it.



3. Connect the power supply and ground cable as shown in the figure below.



6.8 Piping

⚠ Caution

- Connect piping firmly. Incorrect piping might cause leakage of supplied or drained fluid and wet surrounding area and facility.
- Use caution not to allow dust, chips, cutting oil and other foreign matter to enter the water circuit, etc. during connection of piping.
- During piping work, residual liquid may drip from the circulating fluid circuit or facility water circuit. Prepare a drain pan near the pipe connection so that the residual liquid can be received.
- Securely connect the piping at the piping port with specific wrench when tightening.
- Incorrect piping can burst in service.
- Use non-corrosive material for fluid contact parts of circulating fluid and/or facility water.
- Do not use corrosive material such as aluminium or iron for fluid contact parts, such as piping. Using such materials may lead to clogging or leakage in the circulating fluid and facility water circuits. Also, it may cause refrigerant leak and other unexpected problems.
- Do not generate a rapid change of pressure by water hammer, etc. Internal parts of the product and/or the piping may be damaged.
- It is recommended to use heat insulation to reduce the heat radiation and absorption to/from customer's piping.
- The circuit to be connected to this product must be provided with a mechanism (such as relief valve) to safely release abnormal pressure.

6 Installation (continued)

6.8.1 Piping Port Size

Name	Port size	Recommend tightening torque	Recommended piping specification
Circulating fluid outlet port	Rc1	36 to 38N·m	1.0MPa and more
Circulating fluid return port	Rc1	36 to 38N·m	1.0MPa and more
Facility water inlet port	Rc1	36 to 38N·m	1.0MPa and more (Supply pressure: 0.3 to 0.5 MPa)
Facility water outlet port	Rc1	36 to 38N·m	1.0MPa and more (Automatic fluid fill pressure: 0.2 to 0.5 MPa)
Automatic fluid fill port	Rc3/8	28 to 30N·m	ID25mm or more
Overflow port	Rc1	36 to 38N·m	Length 5 m or less
Pump drain port	Rc3/4	28 to 30N·m	ID 19mm or more

Notes: *Water cooled type only.

For HRSF***-AN/WN-*: A set of thread adapters that converts the connectors from Rc to NPT is enclosed as an accessory. For NPT thread, be sure to use this adapter.

For HRSF***-AF/WF-*: A set of thread adapters that converts the connections from Rc to G is enclosed as an accessory. For G thread, be sure to use this adapter.

6.9 Circulating Fluid Supply

⚠ Caution

- When tap water is used, refer to Operation Manual section "7.1 Quality Control of Circulating Fluid and Facility Water".
- When 15% ethylene glycol aqueous solution is used, dilute pure ethylene glycol with water. Additives cannot be used.
- When deionised water is used, the conductivity should be 1µS/cm or higher (Electrical resistivity: 1MΩ·cm or lower).
- Confirm that the fluid level is between "HIGH" and "LOW" level of the fluid level gauge.
- Confirm that the valve of the drain port is closed to prevent the supplied circulating fluid from draining out.
- When the set circulating fluid temperature and/or the ambient temperature is lower than 10°C, use a 15% aqueous solution of ethylene glycol. Tap water may be frozen in the thermo-chiller which may damage the product.

6.9.1 15% Aqueous Solution of Ethylene Glycol

When a 15% aqueous solution of ethylene glycol is used, prepare the ethylene glycol aqueous solution separately.

To control the density of the ethylene glycol aqueous solution, a densitometer is available (sold separately) from SMC.

Item	Part No	Remarks
Ethylene glycol aqueous solution 60%	HRZ-BR001	Please dilute to 15% with tap water and use it.
Densitometer	HRZ-BR002	---

⚠ Caution


When a 15% aqueous solution of ethylene glycol is used, check the density periodically because the density will be lower due to the automatic fluid-fill function.

6.9.2 Automatic Fluid-Fill Function

Open the fluid supply that is connected to the automatic water fill port. Fluid supply starts and stops automatically with the ball tap in the tank.

⚠ Caution

- Be sure to connect the piping from the overflow port to the sump pit to drain the excessive amount of the fluid from the tank.
- When using a 15% aqueous solution of ethylene glycol, collect the overflowed fluid in the recycling pit and dispose it according to the local law of the country and area that the product is installed.




Piping name	Port size	Piping specification
Automatic fill fluid port	Rc1/2	Supply pressure: 0.2 to 0.5MPa
Overflow port	Rc1	The piping length should be Ø25mm or more and the length of 5 meters or less. Avoid riser piping (trapping part)

6.9.3 Fill of Fluid without using Automatic Fluid-Fill Function


To supply the circulating fluid without using the automatic fluid-fill port, remove the upper panel on the right side, and supply the fluid to the fluid-fill port on top of the tank.

6 Installation (continued)


1. Remove the screws (7 pcs.) to remove the upper panel on the right side



2. Hold the handles and lift the right side panel upper and remove it. Remove the tank lid on top of the tank.



3. Supply the circulating fluid to the fluid-fill port.



6.9.4 For Option K "Fluid-Fill Port"

Open the cap of the fluid-fill port and supply the circulating fluid to the fluid level between "HIGH" and "LOW" levels of the fluid level gauge. Close the cap after supplying

7 Starting the Product

7.1 Before Starting

⚠ Caution

Only people who have sufficient knowledge and experience about the product and its accessories are allowed to start and stop the product.

Check the following points before starting.

• Installation state

Check the product is installed horizontally.

Check that there are no heavy objects on the product, and the external piping is not applying excessive force to the product.

• Connection of cables

Check that the power, ground and I/O signal cables (to be supplied by user) are correctly connected.

• Circulating fluid piping

Check that the circulating fluid piping is correctly connected to the inlet and outlet.

• Piping to automatic fluid-fill port

Confirm that the piping to the automatic fluid-fill port is correctly connected

• Piping to overflow port

Piping must be connected to the overflow port regardless of using or not using the automatic fluid-fill function.

Confirm that the piping to the overflow port is correctly connected.

• Fluid level gauge

Confirm that the fluid level is between "HIGH" and "LOW" levels of the fluid level gauge.

• Facility water piping (For water cooled type)

Check that the piping is correctly connected to the facility water inlet and outlet ports.

Confirm that the facility water source is in operation.

Confirm that the facility water circuit is not closed with a valve, etc.

Note: A water control valve is mounted inside the water-cooled thermo-chiller. For the water-cooled type, facility water may not run without operating the product.

⚠ Caution



Facility water quality must satisfy the quality standard shown in Operation Manual section "7.1 Quality Control of Circulating Fluid and Facility Water" and the conditions shown in section "2. Specifications".

7.2 Preparing for Start

7.2.1 Power Supply

Turn ON the breaker of the user's power supply.

7 Starting the Product (continued)



When the product is switched ON, the operation panel display operates as shown below:

- The initial screen (HELLO screen) is displayed for 8 seconds on the operation display panel. Then, the display moves to the main display which shows the circulating fluid outlet temperature.
- The set circulating fluid temperature is displayed as SV on the digital display.
- The present circulating fluid temperature is displayed as PV on the digital display.

7.2.2 Setting the Circulating Fluid Temperature

Press the [▼] and [▲] button on the operation panel to change the SV to the required value. When setting the circulating fluid temperature by communication, refer to Operation Manual Communication Function.



7.3 Preparation of Circulating Fluid

Circulation fluid is supplied only inside of the product at the time of installation of the thermo-chiller. When the product starts operation in this condition, circulating fluid level will be reduced as the fluid in the level gauge goes down. This is due to the fluid supply to the user's equipment from the thermo-chiller, so additional fluid needs to be supplied to the thermo-chiller.

1. Fill the thermo-chiller with fluid, while it is turned OFF. Then turn ON the thermo-chiller.
2. Press the [PUMP] button on the operation panel (press the

[RUN/STOP] button and the [MENU] button simultaneously).


The pump operates independently while the [PUMP] button is being pressed. The [RUN] light (green) blinks while the pump is operating independently and the circulating fluid in the tank is being supplied to the user's equipment and piping. This finds out leakage from the piping as well as discharges air from the piping.



⚠ Caution

When any external fluid leakage is found with the piping during this operation, stop the individual operation of the pump and fix the leaking part.

If the fluid in the tank reaches the lower limit, a buzzer will be generated, and the alarm number "AL01 (low level in tank)" is displayed as PV on the digital display. The [ALARM] light (red) blinks, the [■] light turns ON, and independent operation of the pump stops.



3. Press the [RESET] button (press the [▼] and [▲] buttons simultaneously to stop the alarm buzzer).



⚠ Caution

Reset alarms on the "Alarm menu" screen. Alarm reset is not accepted from any screen except the "Alarm menu" screen. Refer to Operation Manual section "5.2.1 Key Operations".

4. Fluid supply using automatic water fill function has been started. Operation shown in step 3 can be performed after some minutes.

