
# CKQGK/CKQPK Series 950



## Construction

#### CKQGKC50


\* The below figures indicate the CKQGKC50-□RAL.



- \* There's no seal kit for CLKQGKC50.
- \* The numbers correspond with those in the "Construction" of the CKQ□K/CLKQ□K series in the Best Pneumatics catalog.

#### CKQPKC50

\* The below figures indicate the CKQPKC50-□RAL.



- \* There's no seal kit for CLKQPKC50.
- $\ast$  The numbers correspond with those in the "Construction" of the CKQ $\square$ K/CLKQ $\square$ K series in the Best Pneumatics catalog.

## Seal Kit List

No.	Description	Material	Note
27)	Piston seal		
28	Rod seal	NBR	
29	Tube gasket		

#### Replacement Parts: Seal Kit

Part no.	Content	
CQ2B50-PS	Set of nos. 27, 28, 29	

\* Consult SMC for maintenance service. Seal kit for maintenance of the CLKQ<sup>6</sup> series with lock is not available.

### **Replacement Parts: Grease Pack**

	Grease pack part no.	o. Content		
GR-S-010		Grease 10 g (Lithium)		

\* Consult SMC when replacing the actuating cylinders.

#### Seal Kit List

No.	Description	Material	Note
28	Piston seal		
29	Rod seal	NBR	
30	Tube gasket		

#### Replacement Parts: Seal Kit

Part no.	Content	
CQ2B50-PS	Set of nos. 28, 29, 30	

\* Consult SMC for maintenance service. Seal kit for maintenance of the CLKQ<sup>®</sup> series with lock is not available.

#### **Replacement Parts: Grease Pack**

Grease pack part no.	Content
GR-S-010	Grease 10 g (Lithium)

\* Consult SMC when replacing the actuating cylinders.

Guide Pins Assembly List					
No.	Description	Material	Note		
24	Guide pins assembly	Stainless steel			
14)	Parallel pin	Tool steel			

D ( )			
* Refer to page	211 for the	auide bins	assembly.

-	Clamp Arm Assembly List					
	No.	Description	Material	Note		
	3	Clamp arm	Structural steel			
	15	Cotter pin	Stainless steel			