The Replacement Procedure is on p. 384


Industrial


Air Cylinder/Low Friction Type: Non-lube Type

CS1 Q Series ©125, ©140

Construction

Non-lube type





* The numbers correspond with those in the "Construction" of the CS1 series in the Web Catalog.

Seal Kit List

Ocal Kit List						
No.	Description	Material	Note			
18	Wiper ring					
19	Cushion seal *		19, 24 and 26 are non-replaceable parts, so they are not included in the seal kit.			
20	Rod seal					
21)	Piston seal					
22	Valve seal	NBR				
23	Tube gasket					
24	Piston gasket					
25	Retaining plate gasket					
26	Guide gasket					

* Used with cushion only

Replacement Parts: Seal Kit

	Bore size (mm)	Part no.	Contents	
	125	CS1Q125A-PS	Set of nos. 18, 20, 21, 22, 23, 25	
-	140	CS1Q140A-PS		
	160	CS1Q160A-PS	0,0,0,0,0,0	

* Since the seal kit does not include a grease pack, please arrange with the part numbers listed below only the grease pack separately. In that case, the amount of grease, please refer to the standard type. Grease pack part no.: GR-L-005 (5 g), GR-L-010 (10 g), GR-L-150 (150 g)