
Electro-Pneumatic Regulator/Electronic Vacuum Regulator


ITV Series




SMC

Compact Electro-Pneumatic Regulator ITV0000 Series

Compact Vacuum Regulator IT V009 Series





Stations can easily be increased or decreased due to DIN rail mount design.



| Model | Pressure range | Power supply voltage | Input signal | Output signal | Option | | |
|---------|----------------|----------------------|---------------|----------------------------------------|------------------|-----------------------------------|--|
| ITV001□ | 0.1 MPa | | 4 to 20 mA DC | | Cable connectors | | |
| ITV003□ | 0.5 MPa | | 24 VDC | 24 VDC 0 to 20 mA DC 12 VDC 0 to 5 VDC | Analog output | Straight type Right angle type | |
| ITV005□ | 0.9 MPa | | | | 12 VDC | 12 VDC | |
| ITV009□ | -100 kPa | | 0 10 10 VDC | | L-bracket | | |

Equivalent to IP65

Linearity: ±1% F.S. or less
 Hysteresis: 0.5% F.S. or less
 Repeatability: ±0.5% F.S. or less

High-speed response time: 0.1 sec (Without load)


Note) This is not a guaranteed value as it depends on the operating environment.

High stability



■ Cable connectors

Straight type and right angle type are available.



■ Built-in One-touch fittings

With error indication LED

Brackets

Flat and L-brackets are available.



Electro-Pneumatic Regulator ITV/1000/2000/3000 Series Electronic Vacuum Regulator ITV/209 Series






Serial communications specifications to ITV1000/2000/3000 series are standardized.

Reduced wiring

Applicable Fieldbus protocols


RS-232C specification to serial communications is standardized.


- Sensitivity: 0.2% F.S. or less
- Linearity: ±1% F.S. or less
- Hysteresis: 0.5% F.S. or less
- IP65
- Cable connections in 2 directions



Grease-free specification (ITV1000 series)

Application examples





Electro-Pneumatic Regulator Electronic Vacuum Regulator

Stepless control of air pressure proportional to an electrical signal.

| | | | | 3 | | | |
|-----------------------------|-----------------------------|---------|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------|------|-----------------|
| | Series | Model | Set pressure range | Input signal | Port size | Page | ARJ |
| | ITV0000 Series | ITV001□ | 0.001 to 0.1 MPa | Current type: 4 to 20 mA DC (Sink type) | | | AR425 to 935 |
| ı | | ITV003□ | 0.001 to 0.5 MPa | Current type: 0 to 20 mA DC (Sink type) | Built-in One-touch fittings Metric size: ø4 Inch size: ø5/32 | 896 | AMR |
| ı | 8 | ITV005□ | 0.001 to 0.9 MPa | Voltage type: 0 to 5 VDC Voltage type: 0 to 10 VDC | IIICII SIZE. Ø5/32 | | ARM |
| l. | ITV1000 Series | ITV101□ | 0.005 to 0.1 MPa | | | | ARP IR□-A |
| ulato | | ITV103□ | 0.005 to 0.5 MPa | | 1/8, 1/4 | 904 | IR |
| ic Rec | 73 march 2 | ITV105□ | 0.005 to 0.9 MPa | Current type: 4 to 20 mA DC (Sink type) | | | IRV VEX |
| umat | ITV2000 Series | ITV001 | 0.005 to 0.1 MPa | Current type: 0 to 20 mA DC (Sink type) | | | SRH |
| o-Pne | Electro-Pneumatic Regulator | ITV201 | | Voltage type: 0 to 5 VDC Voltage type: 0 to 10 VDC Preset input (4 points/16 points) | | 004 | SRP |
| Electr | | ITV203□ | 0.005 to 0.5 MPa | | 1/4, 3/8 | 904 | SRF |
| | | ITV205□ | 0.005 to 0.9 MPa | 10 bit digital input CC-Link compatible | | | IC |
| ı | ITV3000 Series | ITV301□ | 0.005 to 0.1 MPa | DeviceNet™ compatible PROFIBUS DP compatible | | | ITVH |
| | | ITV303□ | 0.005 to 0.5 MPa | RS-232C communication | 1/4, 3/8, 1/2 | 904 | PVQ |
| ı | | ITV305□ | 0.005 to 0.9 MPa | | | | VY1 |
| | ITI/000 Corios | | | 0 | | | VBA VBAT |
| n Regulator | ITV009□ Series | ITV009□ | −1 to −100 kPa | Current type: 4 to 20 mA DC (Sink type) Current type: 0 to 20 mA DC (Sink type) Voltage type: 0 to 5 VDC Voltage type: 0 to 10 VDC | Built-in One-touch fittings Metric size: ø4 Inch size: ø5/32 | 928 | AP100 |
| Electronic Vacuum Regulator | ITV209□ Series | ITV209□ | −1.3 to −80 kPa | Current type: 4 to 20 mA DC (Sink type) Current type: 0 to 20 mA DC (Sink type) Voltage type: 0 to 5 VDC Voltage type: 0 to 10 VDC Preset input (4 points/16 points) 10 bit digital input CC-Link compatible PROFIBUS DP compatible PROFIBUS DP compatible RS-232C communication | 1/4 | 935 | |


ITV Series


Compact Electro-Pneumatic Regulator

ITV0000 Series



How to Order





Note) A DIN rail with the length specified by the number of stations is attached to the manifold. For dimensions of the DIN rail, refer to the external dimensions.

How to Order Manifold Assembly (Example)

Indicate the part numbers of electro-pneumatic regulators to be mounted below the manifold part number.

Example)

Due to the common supply/exhaust feature, note that different pressure range combinations are not available.


IITV00-03-----1 set (Manifold part no.)

*ITV0030-3MS-----2 sets (Electro-pneumatic regulator part no. (1, 2 stations))
*ITV0030-3ML-----1 set (Electro-pneumatic regulator part no. (3 stations))

Indicate part numbers in order starting from the first station on -

Note) Combination with having different pressure ranges is not available due to common supply/exhaust features.

The asterisk (*) specifies mounting. Add an asterisk (*) at the beginning of electro-pneumatic regulator part numbers to be mounted.





Compact Electro-Pneumatic Regulator ITV0000 Series

Specifications



| Mode | l | ITV001□ | ITV003□ | ITV005□ | | | |
|-----------------------------------------------|-----------------|--------------------------------------------------|-------------------------------------------------------|------------------|--|--|--|
| Minimum supply p | ressure | S | et pressure +0.1 MF | Pa Pa | | | |
| Maximum supply pressure | | 0.2 MPa | 1.0 MPa | | | | |
| Set pressure range | | 0.001 to 0.1 MPa | 0.001 to 0.5 MPa | 0.001 to 0.9 MPa | | | |
| Voltage | | 24 V | DC ±10%, 12 to 15 | VDC | | | |
| Power supply | Current | Power supply voltage 24 VDC type: 0.12 A or less | | | | | |
| | consumption | Power supply volt | Power supply voltage 12 to 15 VDC type: 0.18 A or les | | | | |
| Input signal | Voltage type | 0 | to 5 VDC, 0 to 10 VE | C | | | |
| input signai | Current type | 4 to 20 mA | DC, 0 to 20 mA DC | (Sink type) | | | |
| Innuit immedence | Voltage type | | Approx. 10 kΩ | | | | |
| Input impedance | Current type | Approx. 250 Ω | | | | | |
| Note 4) | | 1 to 5 VDC (Output impedance: Approx. 1 kΩ) | | | | | |
| Output signal Note 4) | Analog output | Output accuracy: ±6% F.S. or less | | | | | |
| Linearity | Linearity | | ±1% F.S. or less | | | | |
| Hysteresis | | 0.5% F.S. or less | | | | | |
| Repeatability | | ±0.5% F.S. or less | | | | | |
| Sensitivity | | 0.2% F.S. or less | | | | | |
| Temperature chara | acteristics | ±0.12% F.S./°C or less | | | | | |
| Operating tempera | ture range | 0 to 50°C (No condensation) | | | | | |
| Enclosure | | Equivalent to IP65 * | | | | | |
| Connection type | | Bu | ilt-in One-touch fittir | ngs | | | |
| | For single unit | Metric size | Metric size 1, 2, 3: ø4 | | | | |
| Connection size | For single unit | Inch size | 1, 2, 3 | 3: ø5/32" | | | |
| Connection size | Manifold | Metric size | 1, 3: ø | 6, 2: ø4 | | | |
| | IMATITIOIO | Inch size 1, 3: Ø1/4", 2: Ø5/32" | | | | | |
| Weight Note 1) | | 100 | g or less (without op | tion) | | | |
| Note 1\ Indicates the weight of a single unit | | | | | | | |

Note 1) Indicates the weight of a single unit.

For IITV00-n

Total weight (g) Stations (n) x 100 + 130 (Weight of end block A, B assembly) + Weight (g) of DIN rail

Note 2) When there is a downstream flow consumption, pressure may become unstable depending on piping conditions.

Note 3) When the input signal is at 0%, the exhaust solenoid valve is controlled to reduce the outlet pressure to zero. For this reason, a noise may be generated. This noise is normal and does not indicate a fault.

Note 4) When measuring ITV analog output from 1 to 5 VDC, if the load impedance is less than

te 4) When measuring ITV analog output from 1 to 5 VDC, if the load impedance is less tha 100 kΩ, the analog output monitor accuracy of ±6% F.S. or less may not be available. The product with the accuracy of within ±6% is supplied upon your request. Output pressure remains unaffected.

* When using under the conditions equivalent to IP65, connect the fitting or tube to the breathing hole prior to use. (For details, refer to "Specific Product Precautions 1" on page 941.)

Accessories (Option)

Bracket

Flat bracket assembly (includes 2 mounting screws) P39800022



L-bracket assembly (includes 2 mounting screws) P39800023



Tighting torque when assembling is 0.3 N·m.

Cable connector



Right angle type P398000-501-2



ARJ AR425 to 935

ARX AMR ARM

ARP IR□-A

IR

IRV VEX

SRH

SRP

SRF

ITV

IC

ITVH

PVQ

VY1

VBA VBAT


AP100

ITV0000 Series


Working Principle

When the input signal rises, the air supply soloenoid valve ① turns ON. Due to this, part of the supply pressure passes through the air supply solenoid valve ① and changes to output pressure. This output pressure feeds back to the control circuit ④ via the pressure sensor ③. Here, pressure corrections continue until output pressure becomes proportional to the input signal, enabling output pressure that is proportional to the input signal.

Working Principle Diagram





Block Diagram



Compact Electro-Pneumatic Regulator ITV0000 Series

ITV001□ Series





ARJ

AR425 to 935 ARX

AMR

ARM

ARP

IR□-A

IR

IRV

VEX

SRH

SRP

SRF

ITV IC


ITVH


ITVX

PVQ


VY1


AP100







ITV003□ Series













ITV0000 Series

ITV005□ Series










Compact Electro-Pneumatic Regulator ITV0000 Series

Dimensions



ARJ AR425 to 935

ARX AMR

ARM ARP

IR□-A IR

IRV VEX

> SRH SRP

SRF

ITV IC

ITVH


ITVX


PVQ VY1


VBA VBAT AP100


Dimensions

Single unit for manifold










Note) When using under the conditions equivalent to IP65, connect the fittings or tube to the breathing hole prior to use. (For details, refer to "Specific Product Precautions 1" on page 941.)




Note) For dimensions of the cable connector, refer to single unit on page 901.

Compact Electro-Pneumatic Regulator ITV0000 Series

Dimensions


Manifold





| Port Location | | | | | | |
|---------------|------|-----|-----|--|--|--|
| No. 1 2 3 | | | | | | |
| 1 ITV003□ | SLIP | OUT | FYH | | | |

5

Note) Stations are counted starting from the D side.







Note) For dimensions of the cable connector, refer to single unit on page 901.

| | | | | | | | | | (mm) |
|------------------------|-------|-----|-----|-------|-----|-------|-----|-----|-------|
| Manifold stations n | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| L1 | 60 | 75 | 90 | 105 | 120 | 135 | 150 | 165 | 180 |
| L2 | 110.5 | 123 | 148 | 160.5 | 173 | 185.5 | 198 | 223 | 235.5 |
| Weight of DIN rail (g) | 20 | 22 | 27 | 29 | 31 | 34 | 36 | 41 | 43 |

Note) When using under the conditions equivalent to IP65, connect the fittings or tubing to the breathing hole prior to use.

(For details, refer to "Specific Product Precautions 1" on page 941.)



ARJ AR425 to 935 ARX

AMR ARM

ARP

IR□-A

IR IRV

VEX

SRH SRP SRF


Electro-Pneumatic Regulator

ITV1000/2000/3000 Series

CE CRUSUS ROHS



How to Order



For communication cables, use the parts listed below (refer to M8/M12 connector in Best Pneumatics No.1-1 for details)

or order the product certified for the respective protocol (with M12 connector) separately.

| Application | Communication cable part number | Note | |
|-----------------------|---------------------------------|----------------------------------|--|
| CC-Link compatibility | PCA-1567720 (Socket type) | Dedicated Bus adapter supplied | |
| CC-Link compatibility | PCA-1567717 (Plug type) | with the product. | |
| DeviceNet™ | PCA-1557633 (Socket type) | T-branch connector not supplied. | |
| compatibility | PCA-1557646 (Plug type) | 1-branch connector not supplied. | |
| PROFIBUS DP | PCA-1557688 (Socket type) | T-branch connector not supplied. | |
| compatibility | PCA-1557691 (Plug type) | r-branch connector not supplied. | |

Standard Specifications

ITV1000 ITV2000

ITV3000

Symbol

Rated pressure

pressure Output pre (MPa)

0.005MPa

ITV101 Note 8) ITV103 Note 8) ITV105 Note 8) ITV201 ITV203 ITV205 Model ITV301 ITV303 ITV305 Minimum supply pressure Set pressure +0.1 MPa Maximum supply pressure 0.2 MPa 1.0 MPa Set pressure range Note 1) 0.005 to 0.1 MPa 0.005 to 0.5 MPa 0.005 to 0.9 MPa Voltage 24 VDC ± 10%, 12 to 15 VDC Power supply Power supply voltage 24 VDC type: 0.12 A or less Note 9) Current consumption Power supply voltage 12 to 15 VDC type: 0.18 A or less Current type Note 2 4 to 20 mA DC, 0 to 20 mA DC (Sink type) 0 to 5 VDC, 0 to 10 VDC Voltage type Input signal Preset input 4 points (Negative common), 16 points (No common polarity) 10 bit (Parallel) Digital input Current type 250 Ω or less Note 6 Voltage type Approx. 6.5 kΩ Input Power supply voltage 24 VDC type: Approx. 4.7 kΩ impedance Preset input Power supply voltage 12 VDC type: Approx. 2.0 k Ω Digital input Approx. 4.7 $k\Omega$ 1 to 5 VDC (Output impedance: Approx. 1 kΩ) Analog 4 to 20 mA DC (Sink type) (Output impedance: 250 Ω or less) Output signal output Output accuracy ± 6% F.S. or less (monitor Switch NPN open collector output: Max. 30 V, 80 mA output) PNP open collector output: Max. 80 mA output ± 1% F.S. or less Linearity Hysteresis 0.5% F.S. or less ± 0.5% F.S. or less Repeatability 0.2% F.S. or less Sensitivity ± 0.12% F.S./°C or less Temperature characteristics Output pressure Accuracy ± 2% F.S. ± 1 digit or less display Note 4) MPa: 0.001, kgf/cm²: 0.01, bar: 0.01, psi: 0.1 Note 5), kPa: 1 Minimum unit Ambient and fluid temperature 0 to 50°C (No condensation) IP65 Enclosure ITV10□□ Approx. 250 g (without options) Weight Note 10) ITV20□□ Approx. 350 g (without options)

Note 1) Please refer to Figure 1 for the relationship between set pressure and input. Because the maximum set pres-

Approx. 645 g (without options)

sure differs for each pressure display, refer to page 945.

Note 2) 2-wire type 4 to 20 mA DC is not available. Power supply voltage (24 VDC or 12 to 15 VDC) is required. Note 3) Select either analog output or switch output.

Further, when switch output is selected, select either NPN output or PNP output.

When measuring ITV analog output from 1 to 5 VDC, if the load impedance is less than 100 $k\Omega$, the analog output monitor accuracy of within $\pm 6\%$ (full span) may not be available. The product with the accuracy of

within ±6% is supplied upon your request. Output pressure remains unaffected.

Note 4) Adjustment of numerical values such as the zero/span adjustment or preset input type is set based on the minimum units for output pressure display (e.g. 0.001 to 0.500 MPa). Note that the unit cannot be changed. Note 5) The minimum unit for 0.9 MPa (130 psi) types is 1 psi.

Note 6) Value for the state with no over current circuit included. If an allowance is provided for an over current circuit, the input impedance varies depending on the input current. This is 350 Ω or less for an input current of 20 mA DC.

Note 7) The above characteristics are confined to the static state. When air is consumed on the output side, the pres-Note 8) The ITV1000 series is a Grease-free specification (Wetted parts).

ITV30□□

Note 9) Refer to the table below for communication specifications.

Note 10) Add 50 g for digital input type, 70 g for 16 points preset input type respectively.

Communication Specifications (CC, DE, PR, RC)

This range is outside

Input signal (%F.S.)

Figure 1. Input/output characteristics chart

f the control (output)

Serial-communications

model

| Model | | ITV□0□0-CC | ITV□0□0-DE | ITV□0□0-PR | ITV□0□0-RC |
|-----------------------------|----------------------------|----------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|-----------------------------------------|--------------------------|
| Protocol | | CC-Link | DeviceNet™ | PROFIBUS DP | RS-232C |
| Version Note 1) | | Ver 1.10 | Volume1 (Edition3.8), Volume3 (Edition1.5) | DP-V0 | _ |
| Communication speed | | 156 k/625 k 2.5 M/5 M/10 M bps | 9.6 k/19.2 k/45.45 k 93.75 k/187.5 k/500 k 93.75 k/187.5 k/500 k 1.5 M/3 M/6 M/12 M bps | | 9.6 kbps |
| Configula | ation file Note 2) | _ | EDS | GSD | _ |
| | pation area utput data) | 4 word/4 word, 32 bit/32 bit (per station, remote device station) | 16 bit/16 bit | 16 bit/16 bit | _ |
| Communicati | ion data resolution | 12 bit (4096 resolution) | 12 bit (4096 resolution) | 12 bit (4096 resolution) | 10 bit (1024 resolution) |
| Fail safe | | HOLD Note 3)/CLEAR (Switch setting) | HOLD/CLEAR (Switch setting) | CLEAR | HOLD |
| Electric insulation Note 4) | | Insulation | Insulation | Insulation | Non-insulation |
| | ting resistor | Built into the product (Switch setting) | Not built into the product | Built into the product (Switch setting) | _ |
| Current c | consumption | 0.16 A or less | 0.14 A or less | 0.16 A or less | 0.12 A or less |
| | ITV1000 | 330 | 320 | 350 | 320 |
| Weight | ITV2000 | 430 | 420 | 450 | 420 |
| _ | ITV3000 | 730 | 720 | 750 | 720 |

Note 1) Note that version information is subject to change.

Note 2) Configuration files can be downloaded from the operation manual page on SMC's website:http://www.smcworld.com Note 3) The output HOLD value when a CC-Link communications error occurs can be set based on the bit area data.

Note 4) The insulation between the electrical signal of the communication system and ITV power supply

ARJ AR425 to 935

ARX

AMR ARM

ARP

IR□-A IR

IRV VEX

SRH SRP

SRF

ITV

IC


ITVH


ITVX PVQ

VY1

VBA VBAT

AP100





Made to Order

(Refer to pages 922 to 926 for details.)

| Symbol | Specifications | | | | |
|------------|---------------------------------------------------------|--|--|--|--|
| X102 | Reverse type | | | | |
| X224 | High pressure type (SUP 1.2 MPa, OUT 1.0 MPa) | | | | |
| X25 | Set pressure range 1 to 100 kPa (Except ITV3000 series) | | | | |
| X88 | High speed response type (Except ITV3000 series) | | | | |
| X26 | X26 For manifold mounting (Except ITV3000 series) | | | | |
| X410 | Linearity: ±0.5% F.S. or less | | | | |
| X420 | X420 With alarm output | | | | |
| Note 1) Ma | nifoldo ara compatible with 2 to 8 stations | | | | |

Note 1) Manifolds are compatible with 2 to 8 stations Consult with SMC for 9 stations or more.

Note 2) Products without symbols are also compatible. Consult with SMC separately.

Note 3) Compliant with CE marking

| Model | Bracket tightening torque | | |
|--------------|---------------------------|--|--|
| ITV1000 | 0.76 ± 0.05 N·m | | |
| ITV2000/3000 | 1.5 ± 0.05 N·m | | |

Modular Products and Accessory Combinations

| Applicable products and accessories | Applicable model | | | | |
|-------------------------------------|------------------|---------|--|--|--|
| Applicable products and accessories | ITV20□□ | ITV30□□ | | | |
| ① Air filter | AF30-A | AF40-A | | | |
| ② Mist separator | AFM30-A | AFM40-A | | | |
| ③ L-bracket | B310L-A | B410L-A | | | |
| 4 Spacer | Y30-A | Y40-A | | | |
| 5 Spacer with L-bracket (3 + 4) | Y30L-A | Y40L-A | | | |
| 6 Spacer with T-bracket | _ | Y40T-A | | | |

* For ITV10 ., use a modular adapter (Refer to page 643 for details).

Accessories (Option)/Part No.

[Bracket]

| Applicable model | Description | Part No. |
|------------------|-----------------------------------------------------------------------|-------------|
| ITV10□□ | Flat has also to a second by (in all all as a second in a second in a | P398010-600 |
| ITV20□□, 30□□ | Flat bracket assembly (including mounting screws) | P398020-600 |
| ITV10□□ | I hypothet comply (including mounting covery) | P398010-601 |
| ITV20□□, 30□□ | L-bracket assembly (including mounting screws) | P398020-601 |

[Cable connector]

| Cable conflector | | | | | | |
|------------------------------|----------------------------|----------------------|---------------|--|--|--|
| Applicable model | Description | | Part No. | | | |
| Current type Voltage type | Cable connector (4 cores) | Straight type 3 m | P398020-500-3 | | | |
| 4 points preset input | Cable conflector (4 cores) | Right angle type 3 m | P398020-501-3 | | | |
| | Bower cable (4 cores) | Straight type 3 m | P398020-500-3 | | | |
| 16 points preset input | Power cable (4 cores) | Right angle type 3 m | P398020-501-3 | | | |
| | Signal cable (5 cores) | Straight type 3 m | P398020-502-3 | | | |
| | | Right angle type 3 m | P398020-503-3 | | | |
| 10 bit digital input | Cable connector (13 cores) | Straight type 3 m | INI-398-0-59 | | | |
| CC-Link PROFIBUS DP | Power cable (4 cores) | Straight type 3 m | P398020-500-3 | | | |
| DeviceNet™ | . 6.1.6. 6.2.6 (1.66.66) | Right angle type 3 m | P398020-501-3 | | | |
| | Dower cable (4 cares) | Straight type 3 m | P398020-500-3 | | | |
| | Power cable (4 cores) | Right angle type 3 m | P398020-501-3 | | | |
| RS-232C | Communication cables | Straight type 3 m | P398020-502-3 | | | |
| | connector (5 cores) | Right angle type 3 m | P398020-503-3 | | | |

Note 1) For the 10-bit digital type, there is no right angle type cable connector.


Note 2) Even when 'with cable connector' is selected the communication cable is not included in the communication model (CC, DE, PR). Please order separately.


[Bus adapter]

| Applicable model | Description | Part No. | |
|------------------|------------------------------------------------------|--------------|--|
| CC-Link | Bus adapter (Bus adapter supplied with the product.) | EX9-ACY00-MJ | |


Dimensions

Flat bracket





L-bracket






Working Principles

When the input signal rises, the air supply solenoid valve ① turns ON, and the exhaust solenoid valve ② turns OFF. Therefore, supply pressure passes through the air supply solenoid valve ① and is applied to the pilot chamber ③. The pressure in the pilot chamber ③ increases and operates on the upper surface of the diaphragm ④.

As a result, the air supply valve \S linked to the diaphragm \P opens, and a portion of the supply pressure becomes output pressure.

This output pressure feeds back to the control circuit ® via the pressure sensor ⑦. Here, a correct operation functions until the output pressure is proportional to the input signal, making it possible to always obtain output pressure proportional to the input signal.

Working Principle Diagram Pressure display ® Control Output signal Power supply Input signal circuit (7) Pressure sensor Pressure display ② Exhaust Air supply solenoid solenoid Power supply Output signal (8) Control valve valve circuit Input signal (7) Pressure sensor **EXH** 1 Air supply 2 Exhaust solenoid solenoid valve valve 4 Diaphragm 3 Pilot chamber EXH 6 Exhaust valve (4) Diaphragm Supply 3 Pilot chamber **EXH** valve Supply valve OUT SUP OUT SUP **EXH** 6 Exhaust valve ITV1000 ITV2000, 3000



ØSMC

AR425 to 935

to 935

AMR

ARM

ARP IR□-A

IR IRV

VEX

SRH

SRF

ITV IC

ITVH


ITVX

PVQ VY1


VBAT VBAT

ITV101□ Series


Linearity




Hysteresis




Repeatability




Pressure characteristics Set pressure: 0.05 MPa




Flow rate characteristics Supply pressure: 0.2 MPa




Relief flow characteristics




ITV201□ Series




Hysteresis




Repeatability




Pressure characteristics Set pressure: 0.05 MPa



Flow rate characteristics Supply pressure: 0.2 MPa




Relief flow characteristics Supply pressure: 0.2 MPa





ITV301□ Series





Hysteresis






ARM ARP

ARJ


AR425 to 935

ARX


AMR



Flow rate characteristics Supply pressure: 0.2 MPa



Relief flow characteristics Supply pressure: 0.2 MPa



IR IRV

IR□-A

VEX

SRH SRP

SRF

ITV

IC

ITVH


ITVX PVQ

VY1 VBA VBAT


AP100

ITV103□ Series







Hysteresis




Repeatability




Pressure characteristics Set pressure: 0.2 MPa






Relief flow characteristics




ITV203□ Series


Linearity




Hysteresis




Repeatability




Pressure characteristics Set pressure: 0.2 MPa



Flow rate characteristics Supply pressure: 0.7 MPa




Relief flow characteristics Supply pressure: 0.7 MPa





ITV303□ Series





Hysteresis





ARM ARP

IR□-A


IR


ARJ


AR425 to 935

ARX


AMR







Relief flow characteristics Supply pressure: 0.7 MPa



VEX SRH

IRV

SRP

SRF

ITV

IC

ITVH

ITVX


PVQ VY1

VBA VBAT


AP100

ITV105□ Series


Linearity




Hysteresis




Repeatability




Pressure characteristics




Flow rate characteristics Supply pressure: 1.0 MPa




Relief flow characteristics Supply pressure: 1.0 MPa




ITV205□ Series




Hysteresis




Repeatability




Pressure characteristics Set pressure: 0.4 MPa








Relief flow characteristics Supply pressure: 1.0 MPa





ITV305□ Series














IRV VEX SRH SRP

ARJ

AR425 to 935

ARX

AMR

ARM

ARP

IR□-A

IR

SRF ITV IC

ITVH


ITVX PVQ

VY1 VBA VBAT

AP100

Construction

ITV1000




Main Component Parts

| | No. | Description | Material | | |
|---|-----|---------------------------|-----------------------|--|--|
| | | Description | | | |
| • | 1 | Body | Aluminum alloy | | |
| | 2 | Cover | Aluminum alloy | | |
| • | 3 | Valve guide | Resin | | |
| | 4 | | Aluminum alloy | | |
| • | | Diaphragm assembly | Weather resistant NBR | | |
| | | | Steel | | |
| | 5 | Seal | NBR | | |
| | 6 | Bowl assembly | Resin | | |
| | 0 | Bowl assembly | Silicone rubber | | |
| | 7 | Sub-plate | Resin | | |
| | 8 | Seal | NBR | | |
| | 9 | Control circuit assembly | _ | | |
| • | 10 | Bumper | NBR | | |
| • | 11 | Valve | Stainless steel | | |
| | " | vaive | HNBR | | |
| • | 12 | Guide retainer | Aluminum alloy | | |
| | 13 | Solenoid valve | _ | | |
| • | 14 | O-ring | HNBR | | |
| | 15 | Round head phillips screw | Steel | | |
| • | 16 | Flat washer | Stainless steel | | |
| | | | | | |

^{*} Parts in contact with fluid are indicated with a mark .

ITV2000




Main Component Parts

| | Main Component Parts | | | | | | |
|------------------------|-------------------------------------------------------------------------------------|---------------------------|------------------------|--|--|--|--|
| | No. | Description | Material | | | | |
| • | 1 | Body | Aluminum alloy | | | | |
| * | 2 | Intermediate body | Aluminum alloy | | | | |
| | 3 | Cover | Aluminum alloy | | | | |
| • | | Valve guide | Aluminum alloy | | | | |
| ◆ 5 Valve (Supply valv | | Valve (Supply valve) | HNBR/Brass | | | | |
| | | Valve (Exhaust valve) | lve) HNBR/Brass | | | | |
| ◆ | 7 | Valve spring | Stainless steel | | | | |
| ◆ 8 Valve spring | | Valve spring | Stainless steel | | | | |
| | | | Stainless steel | | | | |
| | | Disabas and seconds. | Aluminum alloy | | | | |
| • | 9 | Diaphragm assembly | Weather resistant NBR | | | | |
| | | | Steel | | | | |
| ۰ | 10 | Seal | NBR | | | | |
| * | 11 Bias spring Stainless st 12 O-ring NBR | | Stainless steel | | | | |
| ٠ | | | NBR Stainless steel | | | | |
| ♦ | | | | | | | |
| ♦ | 14 | Wear ring | Resin | | | | |
| | 15 | Seal | NBR | | | | |
| | 16 | Boul secombly | Resin | | | | |
| | 16 | Bowl assembly | Silicone rubber | | | | |
| _ | 17 | Sub-plate | Resin | | | | |
| | 18 | Seal | | | | | |
| | 19 | Control circuit assembly | _ | | | | |
| - | 20 | Solenoid valve | | | | | |
| • | 21 | O-ring | NBR | | | | |
| | 22 | O-ring | NBR | | | | |
| - | 23 | Round head phillips screw | Steel | | | | |
| - 7 | 5 | | | | | | |

^{*} Parts in contact with fluid are indicated with a mark .

Construction

ITV3000



| No. | Description | Material | |
|-----|---------------------------|-----------------------|--|
| 1 | Cover | Aluminum alloy | |
| 2 | Body | Aluminum alloy | |
| 3 | Valve guide | Aluminum alloy | |
| 4 | Bias spring | Stainless steel | |
| 5 | Intermediate body | Aluminum alloy | |
| | | Weather resistant NBR | |
| | | Rolled sheet steel | |
| 6 | Diaphragm assembly | Stainless steel | |
| | , , | Aluminum alloy | |
| | | Steel | |
| 7 | Valve (Supply valve) | HNBR/Brass | |
| 8 | Valve (Exhaust valve) | HNBR/Brass | |
| 9 | Valve spring | Stainless steel | |
| 10 | Seal | NBR | |
| 11 | Seal | NBR | |
| 12 | Rod guide | Brass | |
| 13 | O-ring retainer | Aluminum alloy | |
| 14 | Seal | NBR | |
| 15 | David accombly | Resin | |
| 15 | Bowl assembly | Silicone rubber | |
| 16 | Sub-plate | Resin | |
| 17 | Seal | NBR | |
| 18 | Control circuit assembly | _ | |
| 19 | Solenoid valve | _ | |
| 20 | O-ring | NBR | |
| 21 | O-ring | NBR | |
| 22 | O-ring | NBR | |
| 23 | Round head Phillips screw | Steel | |

 ^{*} Parts in contact with fluid are indicated with a mark ♠.

ARJ AR425 to 935

ARX AMR ARM

ARP

IR IRV

VEX

SRH

SRF

ITV

IC

ITVH

PVQ

VY1
VBA
VBAT


AP100


Dimensions


ITV10□□

Flat bracket


Note) Do not attempt to rotate, as the cable connector does not turn.









L-bracket





Dimensions (16 points preset input, 10 bit digital input, CC-Link, DeviceNet™, PROFIBUS DP and RS-232C



* Dimensions not shown are same as on page 916 With power cable connector * ITV10□0- CC common dimensions

OUT

13.5

Solenoid

valve

EXH

Note) Order communication cable (other than 16 points, RS-232C) separately. (Refer to page 904.)

valve EXH

SUP




SMC

SUP

valve EXH

EXH (3)



ď

OUT

13.5

* Dimensions not shown are same as on page 916.

Solenoid

valve

EXH

Note) Do not attempt to rotate, as the cable connector does not turn.

917


EXH (3)


Dimensions


ITV20□□

Flat bracket


Note) Do not attempt to rotate, as the cable connector does not turn.









L-bracket





Dimensions (16 points preset input, 10 bit digital input, CC-Link, DeviceNet™, PROFIBUS DP and RS-232C)



SMC

Note) Order communication cable

(other than 16 points, RS-232C)

separately. (Refer to page 904.)

919

Note) Do not attempt to rotate,

does not turn.


as the cable connector


Dimensions

ITV30□□


Flat bracket


Note) Do not attempt to rotate, as the cable connector does not turn.






L-bracket





Dimensions (16 points preset input, 10 bit digital input, CC-Link, DeviceNet™, PROFIBUS DP and RS-232C)



SMC

(other than 16 points, RS-232C)

separately. (Refer to page 904.)

921


as the cable connector

does not turn.



Please contact SMC for detailed dimensions, specifications and lead times.






Input signal (%F.S.) Input/output characteristics chart

Note 1) \square in part number is the same model no. for the standard products. Note 2) Except for preset input type and digital input type.

Note 3) For communication models, consult SMC for availability.



Note 1) For preset input type, digital input type and communication models, consult SMC for availability.

| 2 High Pressure Type (SUP 1.2 MPa, OUT 1.0 MPa) |
|-------------------------------------------------|
| ITV105 — X224 |
| ITV205 — X224 |
| ITV305 — X224 |

Note 1) For preset input type, digital input type and communication models, consult SMC for availability.

(E RoHS



ease contact SMC for detailed dimensions, specifications and lead times

4 High-Speed Response Time Type

Pressure response with no load is approx. 0.1 sec.

Note 1) This is not a guaranteed value as it depends on the operating environment

Note 2) When the input signal is at 0%, the exhaust solenoid valve is controlled to reduce the outlet pressure to zero. For this reason, a noise may be generated. This noise is normal and does not indicate a fault.

Note 3) When operating for the first time, be sure that the power supply voltage and supply pressure are appropriate in relation to the operating environment and conditions

Note 4) For this product, by conducting the procedure described below (steps A to D), the parameters compatible with the power supply voltage and supply pressure in use can be obtained

If the desired output pressure values cannot be reached due to fluctuations in the operating conditions, etc., perform this operation.

A) Change the power supply voltage in use by ± 0.4 VDC or more.

B) After inputting the supply pressure used on the inlet side of the ITV, adjust the input signal as described below.

 $(0\% \rightarrow 100\% \rightarrow 0\%)$ (Change it gradually, waiting 10 s or more between each adjustment.)


* Please contact SMC if difficulty inputting signals occurs.

C) Change the power supply voltage according to the operating conditions/requirements, and repeat step B.

D) Input the power supply voltage and a 0% signal, and retain for 6 minutes or more. (Supply pressure is not required.)

When re-obtaining the parameters, we recommend operating with the air sealed in the piping in order to reliably reach the set pressure. In addition, if item A) above cannot be carried out, it is possible to conduct an "Initialize" operation as described in the operation manual in order to reset the parameters of the product to those set at the time of shipment. When conducting an "Initialize" operation, the min. set pressure (F_1) and the max. set pressure (F 2) will be reset.

Note 5) There is no gain or sensitivity adjustment function.



ARX AMR

ARJ

AR425

to 935

ARM

ARP

IR□-A

IR

IRV

VEX

SRH

SRP SRF

ITV

IC

ITVH

ITVX PVO

VY1

VBA VBAT

AP100

(E CAL US ROHS




Please contact SMC for detailed dimensions, specifications and lead times

5 Manifold Specifications (Except ITV3000 series)

2 through 8 station manifold

How to Order Manifolds



How to Order for Manifold Mounted



Note 1) ☐ in part number is the same model no. for the standard products.

Note 2) For communication models, consult SMC for availability.

Note 3) The thread type is Rc only.

Note 4) For ITV1000 series, the port size is 1/8 only.


Note 5) For ITV2000 series, the port size is 1/4 only.

Note 6) The bracket accessory can not be selected. Note 7) Not applicable to ITV3000 series

| IITV20-02-31 set (3 station manifold base part no.) |
|-----------------------------------------------------------------------|
| ` ' ' |
| *ITV1030-311S-X261 set (Electro-pneumatic regulator part no.) Note 2) |
| *P398020-131 set (Blanking plate assembly part no.) |
| *ITV2050-212S-X261 set (Electro-pneumatic regulator part no.) Note 2) |
| The * is the symbol for mounting. Add the * symbol at the |

beginning of part numbers for electro-pneumatic regulators, etc. to be mounted on the base

How to Order Manifold Assemblies



Note) Refer to the table below for possible mixed combination.

| Model | ITV101□ | ITV103□ | ITV105□ | ITV201□ | ITV203□ | ITV205□ |
|---------|---------|---------|---------|---------|---------|---------|
| ITV101□ | • | _ | _ | • | _ | _ |
| ITV103□ | _ | • | • | _ | • | • |
| ITV105□ | _ | • | • | _ | • | • |
| ITV201□ | • | _ | _ | • | _ | _ |
| ITV203□ | _ | • | • | _ | • | • |
| ITV205□ | _ | • | • | _ | • | • |

Note 1) Electro-pneumatic regulators are counted starting from station 1 on the left side with the OUT ports in front.

Note 2) The port size for mounted electro-pneumatic regulators is Rc 1/8 (ITV1000), Rc 1/4 (ITV2000) only.

Note 3) When there is a large number of stations, use piping with the largest possible inside diameter for the supply side, such as steel piping.

Note 4) The use of the straight type cable connector is recommended. To mount right angle type, be certain to check that no possible interference occurs.

Note 5) When mounting a blanking plate and the regulator with different pressure set, please inform SMC of the order of a manifold station beside a purchase order.

(E CAL US ROHS

ARJ

AR425

to 935

ARX

AMR

ARM

ARP

IR□-A

IR

IRV

VEX

SRH

SRP

SRF

ITV

IC

ITVH

ITVX


PVQ

VY1 VBA VBAT AP100

Please contact SMC for detailed dimensions, specifications, and lead times

6 Linearity: $\pm 0.5\%$ F.S. or Less

Application examples: Polishing equipment and peripheral equipment for wafers, LCD glasses, color filters, etc.



The graph shown above is a typical example. (This graph shows that the output pressure curve is in a negative range when compared to the ideal line.)

Specifications

| Fluid | | Air | | |
|-------------------------|---------------|-------------------------------------------------------------------------------------------|--|--|
| Minimum supply pressure | | Set pressure +0.1 MPa | | |
| Maximum supply | pressure | 1.0 MPa (Pressure range 0.1 MPa type: 0.2 MPa) | | |
| Proof pressure | (Supply side) | 1.5 MPa (Pressure range 0.1 MPa type: 0.3 MPa) | | |
| Proof pressure | (Output side) | 1 MPa (Pressure range 0.1 MPa type: 0.2 MPa) | | |
| Set pressure range | ge | 1: 0.005 to 0.1 MPa, 3: 0.005 to 0.5 MPa, 5: 0.005 to 0.9 MPa | | |
| Power supply vo | Itage | 0: 24 VDC ±10%, 1: 12 to 15 VDC | | |
| Current concum | ation | 0.12 A or less (24 VDC ±10% type) | | |
| Current consump | Juon | 0.18 A or less (12 to 15 VDC type) | | |
| Input signal | | 0: 4 to 20 mA, 1: 0 to 20 mA, 2: 0 to 5 VDC, 3: 0 to 10 VDC | | |
| Input impedance | | Voltage type: Approx. 6.5 kΩ, Current type: 250 Ω or less | | |
| Output signal | | Analog output: 1 to 5 VDC/4 to 20 mA DC, Switch output (NPN/PNP) | | |
| Linearity | | ±0.5% F.S. or less | | |
| Hysteresis | | 0.5% F.S. or less | | |
| Repeatability | | ±0.5% F.S. or less | | |
| Sensitivity | | 0.2% F.S. or less | | |
| Temperature cha | racteristics | ±0.12% F.S./°C or less | | |
| 0.44 | Accuracy | ±2% F.S. ±1 digit or less | | |
| Output pressure display | Minimum unit | MPa: 0.001, kgf/cm²: 0.01, bar: 0.01, psi: 0.1, kPa: 1 | | |
| Ambient and fluid | temperature | 0 to 50°C (No condensation) | | |
| Enclosure | | IP65 | | |
| Weight | | ITV10□□: Approx. 250 g, ITV20□□: Approx. 350 g, ITV30□□: Approx. 645 g (without brackets) | | |

The above characteristics (specifications) are confined to the static state. When air is consumed on the output side, the pressure may fluctuate.




(E CAL US ROHS

Please contact SMC for detailed dimensions, specifications, and lead times



7 With Alarm Output

Alarm is output if the set pressure is not reached or maintained for 5 seconds or more Application examples: Pressure management for thrust control, etc.



Input signal (% F.S.) Figure 1. Alarm output range

Specifications

Figure 2. Relationship between output pressure and alarm output

| Fluid | | Air | | |
|-------------------------------|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|--|
| Minimum supply pressure | | Set pressure +0.1 MPa | | |
| Maximum supply | pressure | 1.0 MPa (Pressure range 0.1 MPa type: 0.2 MPa) | | |
| Dun of mune and | (Supply side) | 1.5 MPa (Pressure range 0.1 MPa type: 0.3 MPa) | | |
| Proof pressure | (Output side) | 1 MPa (Pressure range 0.1 MPa type: 0.2 MPa) | | |
| Set pressure range | ge | 1: 0.005 to 0.1 MPa, 3: 0.005 to 0.5 MPa, 5: 0.005 to 0.9 MPa | | |
| Power supply vo | tage | 0: 24 VDC ±10%, 1: 12 to 15 VDC | | |
| 0 | | 0.12 A or less (24 VDC ±10% type) | | |
| Current consump | tion | 0.18 A or less (12 to 15 VDC type) | | |
| Input signal | | 0: 4 to 20 mA, 1: 0 to 20 mA, 2: 0 to 5 VDC, 3: 0 to 10 VDC | | |
| Input impedance | | Voltage type: Approx. 6.5 k Ω , Current type: 250 Ω or less | | |
| Output signal | | Alarm output (NPN/PNP) | | |
| Linearity | | ±1.0% F.S. or less | | |
| Hysteresis | | 0.5% F.S. or less | | |
| Repeatability | | ±0.5% F.S. or less | | |
| Sensitivity | | 0.2% F.S. or less | | |
| Temperature cha | racteristics | ±0.12% F.S./°C or less | | |
| Output pressure display | Accuracy | ±2% F.S. ±1 digit or less | | |
| Output pressure display | Minimum unit | MPa: 0.001, kgf/cm²: 0.01, bar: 0.01, psi: 0.1, kPa: 1 | | |
| Ambient and fluid temperature | | 0 to 50°C (No condensation) | | |
| Enclosure | | IP65 | | |
| Weight | | ITV10□□: Approx. 250 g, ITV20□□: Approx. 350 g, ITV30□□: Approx. 645 g (without brackets) | | |
| | | A second section of the | | |

ARJ

AR425 to 935

ARX

AMR

ARM

IR□-A

IR

IRV

VEX

SRH SRP

SRF

ITV

IC

ITVH ITVX

PVQ

VY1


VBA VBAT AP100

Compact Vacuum Regulator


ITV009□ Series

How to Order









Note) A DIN rail with the length specified by the number of stations is attached to the manifold. For dimensions of the DIN rail, refer to the external dimensions.

ø6 (Light gray) ø1/4" (Orange)

How to Order Manifold Assembly (Example)

Indicate the part numbers of electro-pneumatic regulators to be mounted below the manifold part number.

Example)

Due to the common supply/exhaust feature, note that different pressure range combinations are not available.


IITV00-03.....1 set (Manifold part no.)

* ITV0090-3MS-----2 sets (Vacuum regulator part no. (1, 2 stations))

* ITV0090-3ML----1 set (Vacuum regulator part no. (3 stations)) Indicate part numbers in order starting from the first station on the D side

> → Note)Combination with having different pressure ranges is not available due to common supply/exhaust features.

The asterisk (*) specifies mounting. Add an asterisk (*) at the beginning of electro-pneumatic regulator part numbers to be mounted.





Compact Vacuum Regulator ITV009 Series

Specifications



| Model | | | ITV009□ | |
|-------------------------|---------------------|-------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|--|
| Minimum supply pressure | | Set pressure –1 kPa | | |
| Maximum supply pressure | | -101 kPa | | |
| Set pressure range |) | | -1 to -100 kPa | |
| | Voltage | | 24 VDC ±10%, 12 to 15 VDC | |
| Power supply | Current consumption | | oply voltage 24 VDC type: 0.12 A or less y voltage 12 to 15 VDC type: 0.18 A or less | |
| Input signal | Voltage type | | 0 to 5 VDC, 0 to 10 VDC | |
| input signai | Current type | 4 to 20 | 0 mA DC, 0 to 20 mA DC (Sink type) | |
| Input impedance | Voltage type | | Approx. 10 kΩ | |
| input impedance | Current type | | Approx. 250 Ω | |
| Output signal Note 4) | Analog output | 1 to 5 VDC (Output impedance: Approx. 1 kΩ) Output accuracy: ±6% F.S. or less | | |
| Linearity | | | ±1% F.S. or less | |
| Hysteresis | | | 0.5% F.S. or less | |
| Repeatability | | ±0.5% F.S. or less | | |
| Sensitivity | | 0.2% F.S. or less | | |
| Temperature chara | cteristics | ±0.12% F.S./°C or less | | |
| Operating tempera | ture range | 0 to 50°C (No condensation) | | |
| Enclosure | | | IP65 equivalent * | |
| Connection type | | | Built-in One-touch fittings | |
| | For single | Metric size | 1, 2, 3: ø4 | |
| Connection size | unit | Inch size | 1, 2, 3: ø5/32" | |
| Connection size | Manifold | Metric size | 1, 3: ø6, 2: ø4 | |
| | Mannold | Inch size | 1, 3: ø1/4", 2: ø5/32" | |
| Weight Note 1) | | 100 g or less (without option) | | |

Note 1) Indicates the weight of a single unit.

For IITV00-n

Total weight (g) Stations (n) x 100 + 130 (Weight of end block A, B assembly) + Weight (g) of DIN rail

Note 2) When there is a downstream flow consumption, pressure may become unstable depending on piping conditions.

Note 3) When the power is turned on, a noise may be generated. This noise is normal and does not indicate a fault.

Note 4) When measuring ITV analog output from 1 to 5 VDC, if the load impedance is less than

100 k Ω , the analog output monitor accuracy of ±6% F.S. or less may not be available. The product with the accuracy of within ±6% is supplied upon your request. Output pressure remains unaffected.

* When using under the conditions equivalent to IP65, connect the fitting or tube to the breathing hole prior to use. (For details, refer to "Specific Product Precautions 1" on page 941.)

Accessories (Option)

Bracket

Flat bracket assembly (including 2 mounting screws) P39800022



L-bracket assembly (including 2 mounting screws) P39800023



Tighting torque when assembling is 0.3 N·m.

Cable connector



Right angle type P398000-501-2



AR425 to 935

ARX AMR

ARM ARP

IR□-A

IRV VEX

SRH

SRP SRF

ITV

IC

ITVH

ITVX PVQ

VY1


VBA VBAT




Working Principle

When the input signal rises, the vacuum pressure soloenoid valve ① turns ON. Due to this, part of the vacuum pressure (VAC.) passes through the vacuum pressure solenoid valve ① and changes to a vacuum pressure. This vacuum pressure feeds back to the control circuit ④ via the pressure sensor ③. Here, the vacuum pressure soloenoid valve and the atmospheric pressure soloenoid valve work alternately to make continuous pressure corrections until vacuum pressure becomes proportional to the input signal, thus, supplying vacuum pressure that is consistently proportional to the input signal.

Working Principle Diagram





Block Diagram





Compact Vacuum Regulator $ITV009 \square$ Series

ITV009□ Series









AR425 to 935

ARX

AMR

ARM

ARM

ARP

ARJ

IRV VEX

IR

SRH SRP

SRF

ITV IC


ITVH

ITVX PVQ

VY1

ITV009□ Series


Dimensions





SMC


Dimensions

Single unit for manifold










Note) When using under the conditions equivalent to IP65, connect the fittings or tube to the breathing hole prior to use. (For details, refer to "Specific

(For details, refer to "Specific Product Precautions 1" on page 941.)



Note) For dimensions of the cable connector, refer to single unit on page 932.

ARJ AR425 to 935

ARX

AMR ARM

ARP

IR□-A IR

IRV

VEX

SRH

SRF

ITV IC

ITVH

ITVX PVQ


VY1

VBA VBAT AP100

ITV009□ Series

Dimensions


Manifold




Port Location

| No. | 1 | 2 | 3 |
|---------|-----|-----|-----|
| ITV009□ | VAC | OUT | ATM |

Note) Stations are counted starting from the D side.







Note) For dimensions of the cable connector, refer to single unit on page 932.

| | | | | | | | | | (mm) |
|------------------------|-------|-----|-----|-------|-----|-------|-----|-----|-------|
| Manifold stations n | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| L1 | 60 | 75 | 90 | 105 | 120 | 135 | 150 | 165 | 180 |
| L2 | 110.5 | 123 | 148 | 160.5 | 173 | 185.5 | 198 | 223 | 235.5 |
| Weight of DIN rail (g) | 20 | 22 | 27 | 29 | 31 | 34 | 36 | 41 | 43 |

Note) When using under the conditions equivalent to IP65, connect the fittings or tubing to the breathing hole prior to use.

(For details, refer to "Specific Product Precautions 1" on page 941.)

Electronic Vacuum Regulator

ITV2090/2091 Series

C C CRU'US ROHS



AR425

to 935 ARX

AMR

ARM

ARP

IR□-A

IR

IRV

VEX

SRH

SRP

SRF

IΤV

IC

ITVH

ITVX


PVQ

VY1

VBA VBAT

AP100

How to Order



For communications cables, use the parts listed below (refer to M8/M12 connector in Best Pneumatics No.1-1 for details)


| or order the product certified for the respective protocol (with M12 connector) separately. | | | | | | | |
|---------------------------------------------------------------------------------------------|---------------------------------|----------------------------------|--|--|--|--|--|
| Application | Communication cable part number | Note | | | | | |
| CC-Link compatibility | PCA-1567720 (Socket type) | Dedicated Bus adapter supplied | | | | | |
| CC-LITIK COMPANDING | PCA-1567717 (Plug type) | with the product. | | | | | |
| DeviceNet™ | PCA-1557633 (Socket type) | T-branch connector not supplied. | | | | | |
| compatibility | PCA-1557646 (Plug type) | 1-branch connector not supplied. | | | | | |
| PROFIBUS DP | PCA-1557688 (Socket type) | T-branch connector not supplied. | | | | | |
| compatibility | PCA-1557691 (Plug type) | 1-branch connector not supplied. | | | | | |

Stepless control of vacuum pressure proportional to an electrical signal





Piping/Wiring Diagram



Standard Specifications

| Mod | del | ITV2090 | ITV2091 | | |
|-----------------------------|----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------|--|--|
| Minimum supply vac | uum pressure Note 1) | Set pressure –13.3 kPa | | | |
| Maximum supply va | | -101 | kPa | | |
| Set pressure rang | je | -1.3 to - | -80 kPa | | |
| | Voltage | 24 VDC ±10% | 12 to 15 VDC | | |
| Power supply | Current consumption | Power supply voltage 24 VE Power supply voltage 12 to | | | |
| | Current type Note 2) | 4 to 20 mA DC, 0 to 2 | 20 mA DC (Sink type) | | |
| Input signal Note 7) | Voltage type | 0 to 5 VDC, | 0 to 10 VDC | | |
| input signal 1000 17 | Preset input | 4 points (Negative common), 1 | 6 points (No common polarity) | | |
| | Digital input | 10 bit (F | Parallel) | | |
| | Current type | 250 Ω or | less Note 3) | | |
| | Voltage type | Approx. | 6.5 kΩ | | |
| Input impedance | Preset input | Power supply voltage 24 VDC type: Approx. 4.7 k Ω Power supply voltage 12 VDC type: Approx. 2.0 k Ω | | | |
| | Digital input | Approx. 4.7 kΩ | | | |
| Output signal | Analog output | 1 to 5 VDC (Output impedance: Approx. 1 k Ω) 4 to 20 mA DC (Sink type) (Output impedance: 250 Ω or less) Output accuracy \pm 6% F.S. or less | | | |
| (Monitor output) | Switch output | NPN open collector output: Max. 30 V, 80 mA PNP open collector output: Max. 80 mA | | | |
| Linearity | | ± 1% F.S. or less | | | |
| Hysteresis | | 0.5% F.S | S. or less | | |
| Repeatability | | ± 0.5% F.S. or less | | | |
| Sensitivity | | 0.2% F.S. or less | | | |
| Temperature characteristics | | ± 0.12% F.S | | | |
| Output pressure | Accuracy | ± 2% F.S. ± 1 | | | |
| display | Units | kPa Note 5) Minimum display: 1 | | | |
| Ambient and fluid | I temperature | 0 to 50°C (No condensation) | | | |
| Enclosure | | IP65 | | | |
| Weight Note 7, 8) | | 390 | O g | | |

Note 1) The minimum supply vacuum pressure should be 13.3 kPa less than the maximum vacuum pressure setting value. Note 2) 4 to 20 mA DC is not possible with the 2-wire type. Power supply voltage (24 VDC or 12 to 15 VDC) is required. Note 3) Value for the state with no over current circuit included. If an allowance is provided for an over current circuit, the input impedance varies depending on the input power supply. This is 350 Ω or less

for an input current of 20 mA DC.

When measuring ITV analog output from 1 to 5 VDC, if the load impedance is less than 100 k Ω , the analog output monitor accuracy of within ±6% (full span) may not be available. The product with the accuracy of within ±6% is supplied upon your request. Output pressure remains unaffected.

Note 4) Either analog output or switch output must be selected. Furthermore, when switch output is selected, either NPN output or PNP output must also be selected. Use caution that the preset input type is not equipped with an output signal function.

Note 5) Please contact SMC regarding indication with other units of pressure.

Note 6) The product characteristics are confined to the static state.

Pressure may fluctuate when air is consumed at the output side.

Note 7) Refer to the table below for communication specifications.

Note 8) Add 50 g for digital input type, 70 g for 16 points preset input type respectively.

Communication Specifications (CC, DE, PR, RC)

| Model | ITV□0□0-CC□□ | ITV□0□0-DE□□ | ITV□0□0-PR□□ | ITV□0□0-RC□□ |
|------------------------------------------------------------------------------|-------------------------------------------------------------------|--------------------------------------------|-------------------------------------------------------------------------|--------------------------|
| Protocol | CC-Link | DeviceNet™ | PROFIBUS DP | RS-232C |
| Version Note 1) | Ver 1.10 | Volume1 (Edition3.8), Volume3 (Edition1.5) | DP-V0 | _ |
| Communication 156 k/625 k speed 2.5 M/5 M/10 M bps | | 125 k/250 k/500 k bps | 9.6 k/19.2 k/45.45 k 93.75 k/187.5 k/500 k 1.5 M/3 M/6 M/12 M bps | 9.6 kbps |
| Configulation file Note 2) | _ | EDS | GSD | _ |
| I/O occupation area (input/output data) | 4 word/4 word, 32 bit/32 bit (per station, remote device station) | 16 bit/16 bit | 16 bit/16 bit | _ |
| Communication data resolution | 12 bit (4096 resolution) | 12 bit (4096 resolution) | 12 bit (4096 resolution) | 10 bit (1024 resolution) |
| Fail safe | HOLD Note 3)/CLEAR (Switch setting) | HOLD/CLEAR (Switch setting) | CLEAR | HOLD |
| Electric insulation Note 4) | Insulation | Insulation | Insulation | Non-insulation |
| Terminating resistor | Built into the product (Switch setting) | Not built into the product | Built into the product (Switch setting) | _ |
| Current consumption | 0.16 A or less | 0.14 A or less | 0.16 A or less | 0.12 A or less |
| Weight ITV2090 | 470 | 460 | 490 | 460 |

Note 1) Note that version information is subject to change.

Note 2) Configuration files can be downloaded from the operation manual page on SMC's website: http://www.smcworld.com
Note 3) The output HOLD value when a CC-Link communications error occurs can be set based on the bit area data.

Note 4) The insulation between the electrical signal of the communication system and ITV power supply



Working Principle


Pressure display Power supply ® Control ►Output signal Input signal circuit M. (7) Pressure sensor 1 Vacuum pressure 2 Atmospheric pressure solenoid valve solenoid valve Atmospheric pressure 4 Diaphragm (3) Pilot chamber Vacuum pressure VAC valve (Vacuum pump, etc. ATM OUT. (Atmospheric pressure) (Set pressure) 6 Atmospheric pressure valve


Working Principle

When the input signal increases, the vacuum pressure solenoid valve (1) turns ON, and the atmospheric pressure solenoid valve ② turns OFF. Because of this, VAC. and the pilot chamber ③ are connected, the pressure in the pilot chamber 3 becomes negative and acts on the top of the diaphragm 4


As a result, the vacuum pressure valve (§) which is linked to the diaphragm (4) opens, VAC. and OUT. are connected, and the set pressure becomes negative.


This negative pressure feeds back to the control circuit ® via the pressure sensor ⑦. Then, a correct operation works until a vacuum pressure proportional to the input signal is reached, and a vacuum pressure is obtained which is always proportional to the input signal.







ITV209 ☐ Series















Repeatability



Flow rate characteristics measurement conditions

- · Exhaust flow rate of the vacuum pump
- used for measurement: 500 L/min (ANR)
- Inlet vacuum pressure: -100 kPa
- (When outlet flow rate is 0 L/min (ANR))
- Maximum flow rate: 132 L/min (ANR) (With inlet vacuum pressure at -39 kPa)



ARJ AR425

to 935 ARX

AMR ARM

ARP

IR□-A

IR

IRV VEX

SRH

SRP

SRF ITV

IC

ITVH ITVX

PVO VY1

VBA VBAT AP100


ITV209□ Series


Dimensions

ITV209□


Flat bracket


Note) Do not attempt to rotate the cable connector, as it does not turn.






L-bracket





Dimensions (16 points preset input, 10 bit digital input, CC-Link, DeviceNet™, PROFIBUS DP and RS-232C)



SMC

Note) Order communication cable (other than 16 points, RS-232C) separately. (Refer to page 904.)

939

Note) Do not attempt to rotate the cable

connector, as it does not turn.

ARJ

AR425 to 935

ARX

AMR ARM

ARP Ir□-A

IR

IRV

VEX

SRH

SRP

SRF

IΤV

IC

ITVH

ITVX

PVQ

VY1 VBA VBAT



Accessories (Option)/Part No.

[Bracket]

| Description | Part No. |
|---------------------------------------------------|-------------|
| Flat bracket assembly (including mounting screws) | P398020-600 |
| L-bracket assembly (including mounting screws) | P398020-601 |

[Cable connector]

| [easie comicotor] | | | | | |
|------------------------------|----------------------------|----------------------|---------------|--|--|
| Applicable model | Descrip | otion | Part No. | | |
| Current type Voltage type | Cable samuestan (4 samue) | Straight type 3 m | P398020-500-3 | | |
| 4 points preset input | Cable connector (4 cores) | Right angle type 3 m | P398020-501-3 | | |
| | Power cable (4 cores) | Straight type 3 m | P398020-500-3 | | |
| 16 points preset input | Power cable (4 cores) | Right angle type 3 m | P398020-501-3 | | |
| 16 points preset input | Signal cable (5 cores) | Straight type 3 m | P398020-502-3 | | |
| | | Right angle type 3 m | P398020-503-3 | | |
| 10 bit digital input | Cable connector (13 cores) | Straight type 3 m | INI-398-0-59 | | |
| CC-Link PROFIBUS DP | Power cable (4 cores) | Straight type 3 m | P398020-500-3 | | |
| DeviceNet™ | rower cable (4 cores) | Right angle type 3 m | P398020-501-3 | | |
| | Downey ashle (4 serse) | Straight type 3 m | P398020-500-3 | | |
| | Power cable (4 cores) | Right angle type 3 m | P398020-501-3 | | |
| RS-232C | Communication cables | Straight type 3 m | P398020-502-3 | | |
| | connector (5 cores) | Right angle type 3 m | P398020-503-3 | | |

Note 1) For the 10-bit digital type, there is no right angle type cable connector.


Note 2) Even when "with cable connector" is selected the communication cable is not included in the communication model (CC, DE, PR). Please order separately.

[Bus adapter]

| [Dus adapter] | | |
|------------------|------------------------------------------------------|--------------|
| Applicable model | Description | Part No. |
| CC-Link | Bus adapter (Bus adapter supplied with the product.) | EX9-ACY00-MJ |


Dimensions





100

L-bracket



| Model | Bracket tightening torque |
|--------------|---------------------------|
| ITV1000 | 0.76 ± 0.05 N·m |
| ITV2000/3000 | 1.5 ± 0.05 N·m |



Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 387 to 391 for Common Precautions.

ITV0000/009 ☐ Series Precautions

Air Supply

- 1. Install an air filter near this product on the supply side. Select a filtration degree of 5 µm or less.
- 2. Compressed air containing large amounts of drainage can cause malfunction of this product and other pneumatic equipment. As a countermeasure, install an aftercooler, air dryer or Drain Catch, etc.
- 3. If large amounts of carbon dust are generated by the compressor, it can accumulate inside this product and cause malfunction.


For details on the above compressed air quality, refer to SMC's "Air Preparation Systems".

Wiring

Connect the cable to the connector on the body with the wiring arranged as shown below. Proceed carefully, as incorrect wiring can cause damage.

Further, use DC power with sufficient capacity and a low ripple.







nector is to downwards (SUP port side). Never turn the connector as it is not designed to turn. Using force to turn the connector will damage the connector couplina.

available. The entry direction

for the right angle type con-



Wiring Diagrams

Current signal type




Vs: Power Supply 24 VDC ±10% 12 to 15 VDC A: Input signals 4 to 20 mA DC 0 to 20 mA DC

Voltage signal type



Vs : Power Supply 24 VDC ±10% 12 to 15 VDC Vin: Input signals 0 to 5 VDC 0 to 10 VDC

Monitor output wiring diagram



Handling

ARJ AR425

to 935

ARX

AMR

ARM

ARP

IR□-A

IRV

VEX

SRH

SRP

SRF

ITV

IC

ITVH

ITVX

PVO

VY1

VBA

VBAT

AP100

∕ Caution

- 1. Do not use a lubricator on the supply side of this product, as this can cause malfunction. When lubrication of terminal equipment is necessary, connect a lubricator on the output side of this equipment.
- 2. If electric power is shut off while pressure is being applied, pressure will be retained on the output side.
 - However, this output pressure is held only temporarily and is not guaranteed. If exhausting of this pressure is desired, shut off the power after reducing the set pressure, and discharge the air using a residual pressure exhaust valve, etc.
- 3. If power to this product is cut off due to a power failure, etc. when it is in a controlled state, output pressure will be retained temporarily. Handle carefully when operating with output pressure released to the atmosphere, as air will continue to flow out.
- 4. If supply pressure to this product is interrupted while the power is still on, the internal solenoid valve will continue to operate and a humming noise may be generated.
 - Since the life of the product may be shortened, shut off the power supply also when supply pressure is shut off.
- 5. This product is adjusted for each specification at the time of shipment from the factory. Avoid careless disassembly or removal of parts, as this can lead to malfunction.
- 6. The optional cable connector is a 4 wire type. When the monitor output (analog output or switch output) is not being used, keep it from touching the other wires as this can cause malfunction.
- 7. Please note that the right angle cable does not rotate and is limited to only one entry direction.
- 8. Take the following steps to avoid malfunction due to noise.
 - 1) Remove power supply noise during operation by installing a line filter, etc. in the AC power line.
 - 2) For avoiding the influence of noise or static electricity, install this product and its wiring as far as possible from strong electric fields such as those of motors and power lines, etc.
 - 3) Be sure to implement protective measures against load surge for induction loads (solenoid valves, relays, etc.).
- 9. The product characteristics are confined to the static state. When air is consumed on the output side, and especially used in the system with large leakage, pressure cannot approach the set pressure and the service life is drastically shortened with a humming noise of the solenoid valve.
- 10. For details on the handling of this product, refer to the operation manual which is included with the product.
- 11. In locations where the body is exposed to water, dust, etc., there is a possibility that moisture or dust could enter the body through the breathing hole. Mount a fitting and tube (M-3AU-3 fitting and TIU01m-mm tube recommended) onto Breathing the breathing hole and run the tube to a lohole M3 x 0.5

cation not exposed to moisture or dust, etc.

0



Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 387 to 391 for Common Precautions.

ITV0000/009 ☐ Series Precautions

Handling

12. If this product will be used in a sealed environment, such as inside an inspection box, a ventilation fan should be installed to ensure adequate ventilation as this product can generate heat in some operating conditions.

When the power is turned on, a noise may be generated as a means of checking the operating condition of the solenoid valve. This noise is normal and does not indicate a fault.

 Each product needs to be powered by one power supply unit.

The wiring of this product has the same common between the GND for power and the signals; there is a possibility that a wrong current occurs and prevents a proper operation if one power supply unit controls multiple electro-pneumatic regulators.

- 14. This product does not have a shut-off valve function. If air pressure is supplied without electric power being applied, output pressure may increase to the pressure equivalent of the supply pressure. Operate the system to shut off the supply pressure when not operating the product.
- 15. For this product, by conducting the procedure described below (steps A to D), the parameters compatible with the power supply voltage and supply pressure in use can be obtained.

If the desired output pressure values cannot be reached due to fluctuations in the operating conditions, etc., perform this operation.

- A) Change the power supply voltage in use by ± 0.4 VDC or more.
- B) After inputting the supply pressure used on the inlet side of the ITV, adjust the input signal as described below.
 - $(0\% \to 100\% \to 0\%)$ (Change it gradually, waiting 10 s or more between each adjustment.)
 - * Please contact SMC if difficulty inputting signals occurs.
- C) Change the power supply voltage according to the operating conditions/requirements, and repeat step B.
- D) Input the power supply voltage and a 0% signal, and retain for 6 minutes or more. (Supply pressure is not required.)

While conducting the procedure stated above, noise may be generated by the solenoid valve. However, this does not affect the obtainment of the parameters. In addition, be sure to conduct the procedure with the air sealed in the piping.

Return of Product

∧ Warning

If the product to be returned is contaminated or is possibly contaminated with substances that are harmful to humans, for safety reasons, please contact SMC beforehand and then employ a specialist cleaning company to decontaminate the product. After the decontamination prescribed above has been carried out, submit a Product Return Request Sheet or the Detoxification/Decontamination Certificate to SMC and await SMC's approval and further instructions before attempting to return the item.

Please refer to the International Chemical Safety Cards (ICSC) for a list of harmful substances.

If you have any further questions, please don't hesitate to contact your SMC sales representative.

ARJ

AR425 to 935

ARX

ARM

ARP

IR□-A

IRV

VEX

SRH

SRF

ITV

IC ITVH

ITVX

PVQ VY1

> VBA VBAT





Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 387 to 391 for Common Precautions.

ITV1000/2000/3000/209 ☐ Series Precautions


Piping

⚠ Warning

 Screw piping together with the recommended proper torque while holding the side that has female threads.


Looseness or faulty sealing will occur if tightening torque is insufficient, while thread damage will result if the torque is excessive. Furthermore, if the side with the female threads is not held while tightening, excessive force will be applied directly to piping brackets, etc. causing damage or other problems.

| | | Recomme | ended proper | torque: N · m |
|-------------------|--------|---------|--------------|---------------|
| Connection thread | 1/8 | 1/4 | 3/8 | 1/2 |
| Torque | 3 to 5 | 8 to 12 | 15 to 20 | 20 to 25 |



Do not allow twisting or bending moment to be applied other than the weight of the equipment itself.

Provide separate support for external piping, as damage may otherwise occur.



 Since excessive moment loads and the propagation of vibrations, etc. can easily result from inflexible piping made of materials such as steel, avoid these problems by using flexible tubing for intermediate connections.

1. Preparation before piping

Before piping is connected, it should be thoroughly blown out with air (flushing) or washed to remove chips, cutting oil and other debris from inside the pipe.

If chips, sealing material or other debris enter into this product, the solenoid valve may buzz, or the outlet pressure may not be output normally.

2. Winding of sealant tape

When screwing together pipes and fittings, etc., be certain that chips from the pipe threads and sealing material do not get inside the piping.

Also, when sealant tape is used, leave 1.5 to 2 thread ridges exposed at the end of the threads.



Operating Environment

⚠ Warning

- Do not operate in locations having an atmosphere of corrosive gases, chemicals, sea water, or where there will be contact with the same.
- Do not operate in locations where vibration or impact occurs.

- In locations where the body is exposed to water, steam, dust, etc., there is a possibility that moisture or dust could enter the body through the EXH (solenoid) ports, thereby causing problems.
- 2. To overcome this, simply install tubing to each port, using the fittings, and extend the tubing so that the other end is at a location where no water splash, etc. occurs. Make sure not to bend, or block the I.D. of the tubing as this will have a detrimental affect on the pressure control.
- Do not operate in locations where vibration or impact occurs.
- In locations which receive direct sunlight, provide a protective cover, etc.
- In locations near heat sources, block off any radiated heat.
- In locations where there is contact with spatter from water, oil or solder etc., implement suitable protective measures.

Air Supply

⚠ Warning

1. Type of fluids

Please consult with SMC when using the product in applications other than compressed air.

Do not use compressed air that contains chemicals, synthetic oils including organic solvents, salt or corrosive gases, etc., as it can cause malfunction.

⚠ Caution

- 1. Install an air filter near this product on the supply side. Select a filtration degree of 5 μ m or less.
- Compressed air containing large amounts of drainage can cause malfunction of this product and other pneumatic equipment. As a countermeasure, install an aftercooler, air dryer or Drain Catch, etc.
- If large amounts of carbon dust are generated by the compressor, it can accumulate inside this product and cause malfunction. For details on the above compressed air quality, refer to SMC's "Air Preparation Systems".



Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 387 to 391 for Common Precautions.

ITV1000/2000/3000/209 ☐ Series Precautions

Handling

∕ Caution

- Do not use a lubricator on the supply side of this product, as this can cause malfunction. When lubrication of terminal equipment is necessary, connect a lubricator on the output side of this equipment.
- 2. If electric power is shut off while pressure is being applied, pressure will be retained on the output side. However, this output pressure is held only temporarily and is not guaranteed. If exhausting of this pressure is desired, shut off the power after reducing the set pressure, and discharge the air using a residual pressure exhaust valve, etc.
- 3. If power to this product is cut off due to a power failure, etc. when it is in a controlled state, output pressure will be retained temporarily. Handle carefully when operating with output pressure released to the atmosphere, as air will continue to flow out.
- 4. If supply pressure to this product is interrupted while the power is still on, the internal solenoid valve will continue to operate and a humming noise may be generated. Since the life of the product may be shortened, shut off the power supply also when supply pressure is shut off.
- 5. The setting side pressure cannot be completely released from this product in the range below 0.005 MPa (or -1.3 kPa for Vacuum models). In cases where the pressure needs to be reduced completely to 0 MPa, install a 3 port valve, etc. on the setting side to discharge the residual pressure.
- This product is adjusted for each specification at the time of shipment from the factory. Avoid careless disassembly or removal of parts, as this can lead to malfunction.
- 7. The optional cable connector is a 4-wire type. When the monitor output (analog output or switch output) is not being used, keep it from touching the other wires as this can cause malfunction.
- 8. When connecting the cable to this product, turn the lock ring of the cable. If a portion other than the lock ring of the cable is turned, it may damage the connector on the body. Turn the lock ring by hand without using a tool.
- The right angle cable does not rotate and is limited to only one entry direction. If the right angle cable is rotated forcibly, the cable may be broken or damaged, or may damage the connector on the body.
- 10. Take the following steps to avoid malfunction due to noise.
 - Remove power supply noise during operation by installing a line filter, etc. in the AC power line.
 - For avoiding the influence of noise or static electricity, install
 this product and its wiring as far as possible from strong
 electric fields such as those of motors and power lines, etc.
 - 3) Be sure to implement protective measures against load surge for induction loads (solenoid valves, relays, etc.).
- 11. Due to the large volume of the output side, a loud exhaust noise will be produced when being used for the purpose of a relief function. Therefore, install a silencer (SMC AN20 or AN40 series) on the exhaust port (EXH port). The port sizes are Rc 1/8, Rc 1/4 and Rc 1/2.
- Specifications on pages 905 and 936 is in case of static environment. Pressure may fluctuate when air is consumed at the output side.

- For details on the handling of this product, refer to the operation manual which is included with the product.
- 14. This product does not have a shut-off valve function. If air pressure is supplied without electric power being applied, output pressure may increase to the pressure equivalent of the supply pressure. Operate the system to shut off the supply pressure when not operating the product.
- 15. The solenoid valves built into this product are consumables. Perform periodic maintenance in environments where the solenoid valves are operated at a high frequency. The parts can be replaced with a solenoid valve assembly. Please contact SMC for the part number.

ARJ

AR425 to 935

ARX

ARM

ARP

IR□-A

IR IRV

VEX

SRH

SRF

ITV

IC ITVH

PVQ

VY1



Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 387 to 391 for Common Precautions.

ITV1000/2000/3000/209 ☐ Series Precautions

Design and Selection


⚠ Caution

- Use the following UL approved products for DC power supply combinations.
- (1) Limited voltage current circuit in accordance with UL 508. A circuit in which power is supplied by the secondary coil of a transformer that meets the following conditions.
 - · Maximum voltage (with no load):
 - 30 Vrms (42.4 V peak) or less
 - Maximum current:
 - (1) 8 A or less (including when short circuited)
 - (2) limited by circuit protector (such as fuse) with the follow-

ing ratings.

| No load voltage (V peak) | Max. current rating |
|----------------------------|---------------------|
| 0 to 20 [V] | 5.0 |
| Over 20 and 30 or less [V] | 100 |
| Over 20 and 30 or less [v] | Peak voltage |

- (2) A circuit (class 2 circuit) with maximum 30 Vrms (42.4 V peak) or less, and a power supply consisting of a class 2 power supply unit confirming to UL1310, or a class 2 transformer confirming to UL1585.
- 2. Operate these products only within the specified voltage. Using voltages beyond the specified levels could cause faults or malfunctions.
- Use 0 V as the baseline for the power supplied to the unit for output, control and input.



Each product needs to be powered by one power supply unit.

The wiring of this product has the same common between the GND for power and the signals; there is a possibility that a wrong current occurs and prevents a proper operation if one power supply unit controls multiple electro-pneumatic regulators.

5. Consult SMC for the usage when the downstream side is released to atmosphere.

This product is a pressure controller. The downstream side being released to atmosphere makes the inlet valve full open, allowing a large amount of atmosphere flow into the body. Consult SMC for the appropriate usage when you use the product under such condition since the product may not meet the specification or the life of the product may be shortened.

ARJ

AR425 to 935

ARX

AMR

ARP

IR□-A

IR

IRV

VEX SRH

SRP

SRF

IC

ITVH

PVQ

VY1






Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 387 to 391 for Common Precautions.

ITV1000/2000/3000/209 ☐ Series Precautions

Wiring

Connect the cable to the connector on the body with the wiring arranged as shown below. Proceed carefully, as incorrect wiring can cause damage. Further, use DC power with sufficient capacity and a



DeviceNet™, RS-232C, 16 points preset

| | IN/ | IN/OUT communication connector | | | | | | | |
|---------|---------------|--------------------------------|-------------------|---------------|------------------------|--|--|--|--|
| Pin No. | CC-Link | DeviceNet™ | PROFIBUS DP | RS-232C | 16 points preset | | | | |
| 1 | SLD [-] | DRAIN [-] | No connection | No connection | Input signal 1 [Brown] | | | | |
| 2 | DB [White] | V+ [Red] | RxD/TxD-N [Green] | TxD [White] | Input signal 2 [White] | | | | |
| 3 | DG [Yellow] | V- [Black] | No connection | RxD [Blue] | Input signal 3 [Blue] | | | | |
| 4 | DA [Blue] | CAN_H [White] | RxD/TxD-P [Red] | GND [Black] | Input signal 4 [Black] | | | | |
| 5 | No connection | CAN_L [Blue] | No connection | No connection | Common [Gray] | | | | |

| | | Power supply connector | | | | | | | | |
|-----------|---------------|------------------------|-----------------------|---------------|------------------|--|--|--|--|--|
| Pin No. | CC-Link | DeviceNet™ | ™ PROFIBUS DP RS-232C | | 16 points preset | | | | | |
| 1 [Brown] | Vcc | Vcc | Vcc | Vcc | Vcc | | | | | |
| 2 [White] | FG | Can not connect | FG | No connection | No connection | | | | | |
| 3 [Blue] | GND | GND | GND | GND | GND | | | | | |
| 4 [Black] | No connection | Can not connect | No connection | FG | Monitor output | | | | | |

Note 1) The indicated wire colors are when a cable connector made by SMC is used. Note 2) The cable is also available in a right angle type. (Communication cable

straight type only)

A right angle type connector is attached facing left (towards the SUP port). On communication models, the connector faces backwards (towards the EXH port). Do not attempt to rotate, as the connector does not turn.

Note 3) Perform the wiring so that no electric potential difference occurs between GND of the power supply and GND of the communication section. If any electric potential difference occurs, this may cause the internal parts to burn out.

■ Trademark Information

DeviceNet™ is a trademark of ODVA

Knock-down connectors * Order separately.

| Application | CC- compa | Link atibility | | eviceNet ¹ ompatibili | | PROFIBUS DP compatibility | | | |
|-------------|--------------|-------------------|--------------|-------------------------------------|--------------------------|---------------------------|----------------|-------------------------------------|--|
| Part number | Plug PCA- | Socket PCA- | Plug PCA- | Socket PCA- | Terminal Plug PCA- | Plug PCA- | Socket PCA- | Terminal Plug PCA- 1557727 | |

Wiring diagram

Current signal type



Vs : Power supply 24 VDC

12 to 15 VDC 4 to 20 mA DC A : Input signal 0 to 20 mA DC

Voltage signal type




Vs : Power supply 24 VDC 12 to 15 VDC

Vin: Input signal 0 to 5 VDC 0 to 10 VDC

4 points preset input type



Vs : Power supply 24 VDC 12 to 15 VDC



One of the preset pressures P1 through P4 is selected by the ON/OFF combination of S1 and S2.

| S1 | OFF | ON | OFF | ON | OFF | ON | OFF | ON |
|-----------------|-----|-----|-----|-----|-----|--------|-----|-----|
| S2 | OFF | OFF | ON | ON | OFF | OFF | ON | ON |
| S3 | OFF | OFF | OFF | OFF | ON | ON | ON | ON |
| S4 | OFF | OFF | OFF | OFF | OFF | ON | ON | ON |
| Preset pressure | P01 | P02 | P03 | P04 | P05 | P14 | P15 | P16 |

(Negative common)

- * For safety reasons, it is recommended that one of the preset pressures be set to 0 MPa.
- * Preset pressures are set based on the minimum unit for output display.

| MPa | kgf/cm ² | bar | psi | kPa |
|-------|---------------------|------|-----|-----|
| 0.001 | 0.01 | 0.01 | 0.1 | 1 |

· Note that this is 1 psi for 130 psi types.

.

| 10 bit digital input t | ype |
|------------------------|-----------------------------|
| Wire color | Signal name |
| Pink-Black 2 | Power supply (24 VDC) |
| Green-Black 2 | Power supply (GND) |
| Blue | Signal Common (No Polarity) |
| Blue-Black 2 | MSB 10 bit |
| Gray-Black 1 | 9 bit |
| Orange-Black 1 | 8 bit |
| Green-Black 1 | 7 bit |
| Pink-Black 1 | 6 bit |
| Blue-Black 1 | 5 bit |
| Gray | 4 bit |
| Orange | 3 bit |
| Green | 2 bit |
| Pink | LSB 1 bit |

Note) The wire color is shown for when an option cable



Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 387 to 391 for Common Precautions.

.

ITV1000/2000/3000/209 ☐ Series Precautions Wiring Monitor output wiring diagram Analog output: Voltage type Analog output: Current type (Sink type) Monitor output voltage White Monitor output voltage Switch output: NPN type Switch output: PNP type Load White Load

*When 80 mA DC or more is applied, detecting device for overcurrentstarts activating and then emits an error signal. (Error number "5")

Set Pressure Range

The set pressure range, by unit of standard measured pressure, is shown in the table below.

Set pressure range, by unit of standard measured pressure

| | | | , , | | | | | | | |
|---------------------|-------|--------------------|-----|---------|----|---------|-------|-----|---------|-------------|
| Unit | | Set pressure range | | | | | | | | |
| Uniii | IT۱ | ITV□01□ | | ITV□03□ | | ITV□05□ | |)5□ | ITV209□ | |
| MPa | 0.005 | to | 0.1 | 0.005 | to | 0.5 | 0.005 | to | 0.9 | _ |
| kgf/cm ² | 0.05 | to | 1 | 0.05 | to | 5 | 0.05 | to | 9 | _ |
| bar | 0.05 | to | 1 | 0.05 | to | 5 | 0.05 | to | 9 | _ |
| psi | 0.7 | to | 15 | 0.7 | to | 70 | 0.7 | to | 130 | _ |
| kPa | 5 | to | 100 | 5 | to | 500 | 5 | to | 900 | -1.3 to -80 |

| CE Marking | | | | | | | | | |
|---------------|--------------|-------------|--|--|--|--|--|--|--|
| TV0000 Series | | | | | | | | | |
| Model | Ferrite core | Recommended | | | | | | | |

M8-4DSX3MG4 (Straight type) ITV0000-□□-Q Unnecessary P398000-501-2 (Right angle type) Note) Recommended power supply cable length is 3 m. (P398000-501-2 is 2

m.) If any other length is desired, please consult with SMC.

• ITV1000/2000/3000 Series

| Model | Ferrite core necessity | | Recommended power supply cable |
|-----------------|------------------------|---------------|-------------------------------------------------------------------|
| ITV===== | | _ | P398020-500-3 (Straight type) P398020-501-3 (Right angle type) |
| ITV□□-52□ | - | Power | P398020-500-3 (Straight type) P398020-501-3 (Right angle type) |
| ITV□□-53□ | | Signal | P398020-502-3 (Straight type) P398020-503-3 (Right angle type) |
| ITV□□-60□ | | _ | INI-398-0-59 (Straight type) |
| ITV 🗆 - CC | Unnecessary | Power | P398020-500-3 (Straight type) P398020-501-3 (Right angle type) |
| Note 2) Note 3) | | Communication | PCA-1567720 (Socket type) PCA-1567717 (Plug type) |
| ITV | | Power | P398020-500-3 (Straight type) P398020-501-3 (Right angle type) |
| Note 2) Note 4) | | Communication | PCA-1557633 (Socket type) PCA-1557646 (Plug type) |
| ITV□□-PR□ | | Power | P398020-500-3 (Straight type) P398020-501-3 (Right angle type) |
| Note 2) Note 4) | | Communication | PCA-1557688 (Socket type) PCA-1557691 (Plug type) |
| ITV□□-RC□ | | Power | P398020-500-3 (Straight type) P398020-501-3 (Right angle type) |
| IIVUU-RCU | | Communication | P398020-502-3 (Straight type) P398020-503-3 (Right angle type) |

Note 1) Recommended power supply cable length is 3 m. If any other length is desired, please consult with SMC.

Note 2) Even when the "with cable connector" type is selected, the communication connector is not included. Refer to the catalog [M8/M12 Connector] CAT.ES100-73 for the details of the communication cable.

Note 3) For CC-Link compatible products, a dedicated Bus adapter is included with the product. Note 4) For DeviceNet™ compatible products, and PROFIBUS DP compatible products, a T-branch connector is not included with the product.

Return of Product

⚠ Warning

If the product to be returned is contaminated or is possibly contaminated with substances that are harmful to humans, for safety reasons, please contact SMC beforehand and then employ a specialist cleaning company to decontaminate the product. After the decontamination prescribed above has been carried out, submit a Product Return Request Sheet or the Detoxification/Decontamination Certificate to SMC and await SMC's approval and further instructions before attempting to return the item. Please refer to the International Chemical Safety Cards (ICSC) for a list of harmful euhetancee

If you have any further questions, please don't hesitate to contact your SMC sales representative.



ARJ

AR425 to 935 ARX

AMR ARM

ARP

IR□-A IR

IRV VEX

> SRH SRP

SRF

IC

ITVH ITVX

PVQ

VY1 VBA

VBAT AP100



Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 387 to 391 for Common Precautions.

ITV009□/209□ Series Precautions

Handling

∕ Caution

- 1. Connect the vacuum pump to the port, which is lab-eled "VAC".
- Pressure adjustment changes from "atmospheric pressure to vacuum pressure" when the input signal is increased, and from "vacuum pressure to atmospheric pressure" when the input signal is decreased.
- 3. When adjusting the vacuum pressure, be careful not to block the atmospheric pressure inlet port labeled "ATM".
- Since this product is designed exclusively for use with negative pressure, be careful not to apply positive pressure in error.
- 5. In cases where the vacuum pump being used has a relatively small capacity, or the piping has a small inside diameter, etc., large variations in the set pressure (the range of pressure variation when changing from no flow to flow state) may appear. In this situation, the vacuum pump or the piping, etc. should be changed. In cases where it is not practical to change the vacuum pump, install a capacity tank (volume depending on the operating conditions) on the VAC side.
- 6. The vacuum pressure response time after a change in the input signal is influenced by the internal volume on the setting side (including piping). Since the capacity of the vacuum pump also influences the response time, give careful consideration to these points before operation.
- 7. If the electric power is shut off when in a control state, the pressure on the setting side will go into a holding condition. However, this setting side pressure will be held only temporarily and is not guaranteed. In addition, when atmospheric pressure is desired, shut off the power after reducing the set pressure, and then introduce atmospheric pressure by using a vacuum release valve, etc.
- 8. If the power for this product is cut off by a power failure, etc. when it is in a controlled state, the setting side pressure will be held temporarily. Further, if operated without sealing the setting side so that atmospheric air is sucked in, handle with care as air will continue to be sucked in.
- 9. If the VAC side pressure to this product is interrupted while the power is still on, the internal solenoid valve will continue to operate and may cause a humming noise. Since this may shorten the life of the product, be sure to shut off the power when the VAC side pressure is shut off.
- 10. The setting side pressure cannot be completely released from this product in the range below -1.3 kPa. In cases where the pressure needs to be reduced completely to 0 kPa, install a 3 port valve, etc. on the setting side to discharge the residual pressure.
- 11. This product is adjusted for each specification at the factory before shipment. Avoid careless disassembly or removal of parts, as this can cause failure.

Handling

- 12. The optional cable connector is a 4-wire type. When the monitor output (analog output, switch output) is not being used, keep it from touching the other wires, as this can cause malfunction.
- Use caution that the right angle cable does not rotate and is limited to only one entry direction.
- Take the following steps to avoid malfunction due to noise.
 - 1) Eliminate power supply noise during operation by installing a line filter, etc. in the AC power line.
 - For avoiding the influence of noise or static electricity, install this product and its wiring as far as possible from strong electric fields such as those of motors and power lines, etc.
 - 3) Make sure to take protective measures against load surge for an induction load (solenoid valves, relays, etc.).
- Refer to the operation manual included with the product for details on its handling.

Return of Product

If the product to be returned is contaminated or is possibly contaminated with substances that are harmful to humans, for safety reasons, please contact SMC beforehand and then employ a specialist cleaning company to decontaminate the product. After the decontamination prescribed above has been carried out, submit a Product Return Request Sheet or the Detoxification/Decontamination Certificate to SMC and await SMC's approval and further instructions before attempting to return the item.

Please refer to the International Chemical Safety Cards (ICSC) for a list of harmful substances.

If you have any further questions, please don't hesitate to contact your SMC sales representative.